



Porodo Soundtec
Harmona
ENC & ANC Headphones

SKU: PD1037



Table of Contents

Product Overview	2
Specifications	2
Schematic View	3
Product Features	4
Package Contents	5
Instructions for Use	5
Safety Precautions	7
Disposal	7
Warranty	8
Contact Us	8

Product Overview


The Harmona ENC & ANC Headphones provide a comfortable listening experience with cushioned over-ear ear cups and a 40mm driver for clear sound. They feature Active Noise Cancellation (ANC) to block external noise, ensuring an immersive audio experience. The headphones support both wireless and wired connectivity, and you can connect to two devices at once using dual Bluetooth pairing. With up to 53 hours of playtime and USB-C charging, they are perfect for extended use. The built-in microphone allows for clear calls, and the EQ mode switch and volume adjustment give you control over your audio.

Specifications

Material	ABS + PU + Metal
Input	5V/1A
Battery Capacity	400mAh
Play Time	53h Max (@50 %Volume), 40h Max (@100 %Volume)
Talk Time	40h Max
Supported Audio Codecs	SBC & AAC
Standby Time	400h
Charging Time	1.5h
Bluetooth Version	6.0

Charging Interface	USB-C
Impedance	32Ω
Sensitivity	105±3dB
Active Noise Cancellation (ANC)	-19±3dB
Speaker Size	40mm
Frequency Response	20Hz-20kHz
Transmission Distance	15m
SNR	104db
Product Weight	240g
Product Size	5× 18 × 21.5cm
Model Number	PD1037

Schematic View



- a.** Next Track
- b.** Previous Track
- c.** Power on/off, pause/play music, answer/hang up calls, activate voice assistance, switch between music and gaming modes
- d.** Switch between normal/ANC modes, switch between 3EQ modes
- e.** Type-C charging port
- f.** 3.5mm audio jack
- g.** Indicator light
- h.** Microphone hole
- i.** Volume control: slide up to increase volume, slide down to decrease volume

Product Features

- a.** Dual Bluetooth Pairing: Connect two devices simultaneously for seamless switching between devices without the need to disconnect and reconnect.
- b.** Active Noise Cancellation (ANC): Enjoy an immersive listening experience with ANC technology that effectively reduces background noise, allowing you to focus on your music or calls.
- c.** 40mm Driver Size: Delivers high-quality sound with clear treble and deep bass, providing an enhanced audio experience for music, calls, and games.
- d.** Cushioned Over-Ear Design: The over-ear ear cups with soft cushioning provide a comfortable fit for extended wear, ensuring a pleasant listening experience without ear discomfort.
- e.** Built-in Microphone: Take calls or use voice assistants easily with the built-in microphone, ensuring clear communication during calls or when giving voice commands.
- f.** Up to 53 Hours of Playtime: With a long-lasting battery, enjoy up to 53 hours of continuous playtime on a single charge, making these headphones ideal for travel or long listening sessions.
- g.** USB-C Charging: Recharge the headphones quickly with the modern USB-C charging port, ensuring efficient and convenient charging.
- h.** EQ Mode Switch: Customize your audio experience with three equalizer (EQ)

modes that let you switch between different sound profiles, depending on your preference.

i. Volume Control: Easily adjust the volume with a simple slide up or down, allowing for quick and convenient volume adjustments while listening to music or on calls.

Package Contents

- 1.** Headset ×1
- 2.** Charging Cable ×1
- 3.** Aux Cable ×1

Instructions for Use

1. Bluetooth Pairing Method:

1.1. Press and hold the power button for 2 seconds. The RGB light will run from bottom to top and back again. The white light will flash as the device enters pairing mode.

1.2. Turn on the Bluetooth device and search for available devices. Choose the headset model name: SIBYL Y9. The blue LED will turn off once pairing is successful.

1.3. The Bluetooth device will show the Bluetooth icon and battery capacity of the headset. The icon may appear differently depending on your device.

2. Bluetooth Music and Calling Method:

2.1. Press the Play/Pause Button () to start playing music. Press it again to pause music.

2.2. Press the () button to answer a call. Press it again to end the call.

2.3. Press and hold the () button for 2 seconds to reject an incoming call.


2.4. Triple-click to activate voice assistance when connected. Double-click to switch between gaming mode and music mode.

2.5. To turn the headset off, press and hold the () button for 3 seconds.


2.6. Long press the Next button (▶▶) to skip to the next track.



2.7. Long press the Previous button (◀◀) to go back to the previous song.




2.8. ANC Mode: Press the ANC button (ANC) to switch between normal and ANC modes (green light indicates ANC is on). Long press to switch between the 3EQ modes (classic/rock/lyric).



2.9. Volume Control: Slide the touch bar upwards to increase the volume and downwards to decrease the volume.

2.10. Aux Mode: The 3.5mm jack is used for AUX mode. Connect the AUX cable to your mobile phone or computer, turn off the Bluetooth, and enter AUX mode.



3. Charging Function:

3.1. Use a Type-C cable to connect the charger or computer USB port for charging. The RGB light will run from bottom to top and back again, flashing the current power indicator. Four lights will appear when fully charged.

3.2. A voice prompt will notify you when the battery is low. A voice prompt will also alert you every five minutes when the battery is nearly empty.

Safety Precautions

1. Avoid placing the product in damp, dusty, oily, or smoky environments, or exposing it to direct sunlight. Do not leave the product inside a vehicle for an extended period, as this may lead to malfunction.
 2. Adjust the volume to a safe level, as high volume may affect your hearing. For safety reasons, avoid using the product while driving or cycling.
 3. Use a soft, dry cloth to clean the product.
 4. Do not use the product during a thunderstorm.
 5. Do not submerge the product in water. The headphones are not waterproof.
 6. Use a charger with an output voltage of DC5V, either from a PC USB port or a certified USB charger. Ensure the charger is safety-certified by a reliable manufacturer.
 7. Bluetooth products are affected by the environment and distance. Please do not use them near an electromagnetic field. If you do not use Bluetooth products for a long time, please charge them once a month to extend the life of Bluetooth.
- Note:** Please charge with an adaptive USB cable. Avoid using a fast charging cable to prevent battery damage.

Disposal

This product contains a rechargeable lithium battery. For safe use, please follow these guidelines:

- a. Do not hit, squeeze, or expose the product to fire.
- b. Avoid exposing it to high-temperature environments.
- c. Do not use the product if it has been soaked.

Additionally, this product must not be disposed of as unsorted household waste. To ensure proper recycling and treatment, please separate it from regular waste, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**