



Porodo Soundtec

**ENC Earbuds Pro II
True Wireless**

SKU: PDSTAIRPRO2WH

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Cleaning and Maintenance	3
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Soundtec ENC Earbuds Pro II by Porodo offer up to 4 hours of playtime with high-quality sound. These true wireless earbuds feature touch and swipe control for easy music and call management. With auto earbud switching and pop-up connection, they connect instantly when taken out of the case. The earbuds also support voice assistant integration and wireless charging for added convenience. ENC technology ensures clear sound even in noisy environments.

Specifications

Model Number	PDSTAIRPRO2
Bluetooth Version	5.3
Working Time	4H
Standby Time	30H (Earbuds)
Standby Time	80 Days (Case)
Wireless Charging Time	12 H
Wired Charging Time	5 H
Transmission Distance	10m
Charging Interface	Type-C

Product Features

- 1. Up to 4 Hours Playtime:** Enjoy up to 4 hours of continuous use on a single charge for an uninterrupted listening experience.
- 2. Touch Control:** Manage music, calls, and other functions easily with intuitive touch controls on the earbuds.
- 3. Swipe Control:** Allows smooth and quick adjustments to music, volume, or calls with a simple swipe gesture on the earbuds.
- 4. Auto Earbud Switching:** The earbuds automatically connect to your device as soon as you take them out of the case, ensuring seamless connectivity.
- 5. Pop-Up Connection:** Open the charging case, and the earbuds instantly connect to your device for quick pairing.
- 6. Voice Assistant Integration:** Access your voice assistant hands-free, making it easier to manage tasks or control music without touching your phone.
- 7. Wireless Charging:** Conveniently charge your earbuds wirelessly, eliminating the need for cables.
- 8. Environmental Noise Cancellation (ENC):** Reduces background noise for clearer audio, even in noisy environments.

Cleaning and Maintenance

To ensure optimal performance and longevity of your Soundtec ENC Earbuds Gen 4, it is important to clean and maintain them regularly.

- 1. Cleaning the Earbuds:** Use a soft, dry cloth to gently wipe the earbuds and remove any dirt or fingerprints. Avoid using harsh chemicals or abrasive materials that could damage the surface. For a deeper clean, lightly dampen the cloth with water and gently wipe down the earbuds.
- 2. Cleaning the Charging Case:** To keep the charging case in good condition, clean the exterior with a soft, dry cloth. For the interior, use a dry cotton swab or soft brush to remove dust or debris. Be careful not to let any moisture enter the charging port.

- 3. Ear Tips Maintenance:** The ear tips should be cleaned regularly to maintain comfort and hygiene. Gently remove them from the earbuds and wash them with mild soap and water. Allow them to air dry completely before reattaching them to the earbuds.
- 4. Storage:** When not in use, store the earbuds in the charging case to protect them from dust and damage. Ensure the case is kept in a cool, dry place, away from direct sunlight or extreme temperatures.
- 5. Battery Care:** To extend battery life, avoid letting the earbuds fully discharge or remain on the charger for extended periods after reaching full charge. Regular charging helps maintain the battery's performance.

Safety Precautions

- 1. Avoid Exposure to Extreme Temperatures:** Do not expose the earbuds or charging case to extreme heat or cold. Keep them away from direct sunlight, heaters, or other sources of excessive heat, as this could damage the internal components and battery.
- 2. Do Not Use While Charging:** For safety reasons, avoid using the earbuds while they are charging. This helps prevent any potential overheating or electrical issues.
- 3. Keep Away from Moisture:** Do not use or store the earbuds in excessively wet or humid environments. Water or moisture can damage the internal electronics. If they come into contact with water, dry them immediately with a soft cloth.
- 4. Avoid Strong Impacts:** Handle the earbuds with care. Dropping them or exposing them to strong impacts can cause internal damage or affect their functionality.
- 5. Use Approved Chargers Only:** Always use the provided charging cable or certified Type-C chargers to charge the earbuds. Using unauthorized or incompatible chargers may cause damage to the battery or reduce charging efficiency.
- 6. Do Not Disassemble:** The earbuds and charging case are not designed to be opened. Do not attempt to disassemble them as this may void the warranty and cause damage to the internal components.

7. Battery Safety: If you notice any swelling, leakage, or other signs of battery damage, stop using the product immediately. Dispose of it properly according to local regulations.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**