

PORODO



Porodo

Kids Writing Tablet

SKU: PDLFST095



Table of Contents

Product Overview	2
Product Features	2
Care and Maintenance	4
Instructions for Use	4
Safety Notes	5
FCC Statement	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo Kids Writing Tablet with Pencil Case is a 2-in-1 product that combines an LCD writing tablet and a pencil case, designed for children. It features a clear, reusable screen that allows easy writing and drawing with the included stylus pencil. The tablet is equipped with a one-key screen lock for added security and a transparent screen for smooth writing and erasing. Its child-friendly design ensures safety with no harm to the eyes.

Product Features

1. LCD Writing Tablet:

a. Reusable Screen: The LCD screen provides a smooth, clear writing surface that can be wiped clean after use, allowing for repeated use without the need for paper. This makes it an eco-friendly alternative to traditional paper and helps reduce waste.

b. Easy Writing and Drawing: The tablet allows children to easily write, draw, and express their creativity with the included stylus pencil. The smooth surface provides a responsive and satisfying writing experience, ideal for both drawing and writing practice.

2. One-Key Screen Lock:

The device is equipped with a one-key screen lock feature, which prevents accidental erasure of the content on the screen. This ensures that children's work remains safe and intact, allowing them to continue their creative process without disruption. Simply press the lock button to secure the screen.

3. Child-Friendly Design:

a. No Harm to Eyes: The LCD screen is designed to be safe for children's eyes, ensuring that they can use the tablet for extended periods without discomfort.

or strain. The screen is free of harmful blue light, making it a safe option for young users.

b. Comfortable Viewing: The screen provides a clear and crisp display, making it easy for children to see their drawings and writings in bright light, with no glare or reflections.

4. Transparent Screen for Easy Erasing:

The transparent screen allows children to easily see their creations and make changes when needed. To erase, simply press the eraser button. The screen clears instantly, allowing for fresh drawings or writings to take place.

5. 2-in-1 Pencil Case:

a. Functional Storage: The pencil case is not only a container for the LCD tablet but also includes ample space for pencils, pens, erasers, and other stationery. This makes it a convenient all-in-one solution for organizing and storing writing and drawing tools.

b. Compact and Durable: The pencil case is made from sturdy materials to protect both the LCD tablet and the stationery. It is designed to withstand the rigors of daily use and is ideal for kids who are always on the go.

6. Stylus Pencil Included:

The tablet comes with a specially designed stylus pencil, which is lightweight, comfortable to hold, and perfect for small hands. The pencil provides a smooth and responsive writing experience on the LCD screen, making it easy for children to draw and write with precision.

7. Portable and Lightweight:

The compact design makes this product easy to carry and ideal for travel. Whether on the go or at home, children can take their writing tablet and pencil case with them, ensuring hours of fun and creativity anytime, anywhere.

8. Durable Construction:

The tablet and pencil case are built with durability in mind. The materials used are lightweight yet strong, providing a long-lasting product that can withstand drops, bumps, and everyday wear and tear.

9. Environmentally Friendly:

By using a reusable LCD screen, this product promotes sustainability by reducing the need for disposable paper and markers. Children can use the writing tablet for years without contributing to paper waste.

10. Safe and Non-Toxic Materials:

The product is made from non-toxic, BPA-free materials that are safe for children. Parents can have peace of mind knowing that the tablet and pencil case are safe for young users.

Care and Maintenance

Cleaning:

To clean the tablet, use a soft, dry cloth to gently wipe the screen. Avoid using water, harsh chemicals, or abrasive materials, as they can damage the screen or the device.

Storage:

When not in use, store the tablet in a dry, cool place to avoid any potential damage from heat or humidity. Always keep the stylus pencil securely in the pencil case to prevent loss or damage.

Instructions for Use

1. Writing and Drawing:

- a.** Use the provided stylus pencil to write or draw on the tablet's screen.
- b.** The transparent screen ensures smooth and clear writing.

2. Erasing:

To erase your writing or drawing, press the "Erase" button.

3. Screen Lock:

To prevent accidental erasure, activate the one-key screen lock by pressing the lock button.

4. Storage:

Open the pencil case and store the stylus pencil and other stationery items inside for safekeeping.

Safety Notes

- a. Not suitable for children under 3 years of age.
- b. Do not use sharp objects or excessive force on the screen.
- c. Always use the tablet under adult supervision.
- d. Do not expose the tablet to water or moisture to prevent damage to the device. Always use it in a dry environment.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference; and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements.

The device can be used in portable exposure conditions without restriction.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**