

PORODO
LIFESTYLE



Porodo Lifestyle
MULTIFUNCTIONAL
TABLET STAND WITH SPEAKER

SKU: PDLFST175BK



Table of Contents

Product Overview	2
Specifications	2
Connection Ports	3
Usage Instructions	3
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Porodo Multifunctional Tablet Stand with Speaker combines convenience and versatility with its 360-degree swivel mount stand and flexible viewing angle. It features Bluetooth 5.0 for seamless connectivity and allows for multiple playback modes, including USB and TF card playback. The built-in speaker enhances audio quality for a superior multimedia experience, and the stand can easily be tilted and rotated for comfortable device positioning. Designed for portability, it also functions as a power bank, ensuring your devices stay charged while in use. With up to 5 hours of music playtime, this tablet stand is ideal for both work and leisure.


Specifications

Speaker Driver	40mm
Rated Power	5W
Battery Capacity	1200mAh
Playtime	5h
Charging Time	2h
Charging Interface	USB-C
Audio Inputs	Bluetooth, AUX, Micro SD, USB Flash Drive

Net Weight	474g
Model Number	PDLFST175

Connection Ports

- 1. USB Port
- 2. AUX
- 3. TF
- 4. DC-5V (Type-c) Charging Input



Usage Instructions

- 1. Press the power button to turn on the tablet stand.
- 2. Enable Bluetooth on your device (smartphone, tablet, or laptop).
- 3. Search for available Bluetooth devices and select "PD-LFST175".
- 4. Once connected, audio will play through the built-in speaker.
- 5. Do not use the device near water or in excessively humid environments while connected via Bluetooth, as this may cause damage.
- 6. Insert a USB flash drive into the USB port at the back of the stand.
- 7. The device will automatically recognize the drive, allowing you to play music or media stored on it.
- 8. Do not force incompatible or damaged USB drives into the port, as this may damage the device.
- 9. Insert a TF card (microSD) into the TF card slot at the back of the stand.

- 10.** The device will detect the card and automatically play compatible audio or media files.
- 11.** Avoid inserting TF cards that are bent, damaged, or incompatible, as this may harm the device.
- 12.** Connect your device to the AUX input using a 3.5mm audio cable.
- 13.** Audio from your device will play through the tablet stand's speaker.
- 14.** Ensure the cable is securely connected and do not pull or bend it excessively, as this may damage the port or cable.
- 15.** Connect a Type-C cable to the charging port at the back of the device.
- 16.** Connect the other end to a DC 5V power source, such as an adapter or USB charger, to charge the battery.
- 17.** Do not charge the device in extremely hot, cold, or wet environments, and do not use incompatible chargers, as this may cause battery damage, overheating, or safety hazards.

Safety Precautions

- 1.** Do not expose the tablet stand or speaker to water or moisture. Keep the device dry at all times to prevent damage to internal components.
- 2.** Always use the recommended charging cable and adapter (DC 5V). Using incompatible chargers or overcharging may cause battery overheating or damage.
- 3.** Do not place the device in direct sunlight or near heat sources. If the device becomes hot during use, turn it off and allow it to cool before resuming use.
- 4.** Handle the device gently when adjusting the stand, tilting, or rotating it to avoid damaging the mounting mechanism.
- 5.** Keep the device out of reach of small children. This product is not a toy and may pose choking hazards or other safety risks.
- 6.** Do not attempt to disassemble or repair the device yourself. Contact authorized service providers for all repairs or servicing.

7. Ensure that charging and data ports are free of debris or obstructions before use to avoid connection issues or damage to the ports.
8. Only connect compatible devices to the stand and speaker to prevent potential damage or malfunction.
9. Avoid prolonged continuous use, especially during high-power tasks, to prevent overheating. Allow the device to rest periodically.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**