

PORODO
LIFESTYLE



Porodo Lifestyle
Thermia
Mini Handheld Steamer

SKU: PDLFSTHG8023WH



Table of Contents

Product Overview	2
Specifications	2
Safety Instructions	3
Filling the Water Tank	3
Operation Instructions	5
Cleaning Guide	5
Steaming Tips	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo Lifestyle Thermia Mini Handheld Steamer is designed for fast, effortless garment care wherever you are. With a powerful 900W output, it heats up and is ready to use in just 25 seconds, making it ideal for quick touch-ups at home or on the go. Its compact, foldable design makes storage and travel simple, while the lightweight build ensures comfortable handling during use. The steamer features an 80mL water tank and delivers a consistent 16g/min steam rate to smooth out wrinkles efficiently. Supporting both vertical and horizontal steaming, it easily handles everyday clothing as well as hard-to-reach areas. The high-temperature panel ensures effective steam distribution, giving you reliable results in a sleek, portable form factor built for modern, busy lifestyles.

Specifications

Rated Voltage	220-240V
Rated Frequency	50Hz
Rated Power	700-900W
Preheat Time	25s
Steam Rate	16±3g/min
Water Tank Capacity	80mL(Detachable)
Steam Working Time	7min Max
Power Cord	190cm
Cord Length	1.9m


Product Weight	0.65kg
Product Size	81 x 175 x 200mm
Model Number	PDLFSTHG8023

Safety Instructions


1. Children are not allowed to use this product. Please keep the machine out of the reach of children.
2. Before connecting to the power supply, check the plug and power cord. If either is damaged, it must be replaced by qualified service personnel to avoid danger.
3. When using this product, make sure the water tank is properly installed.
4. Do not touch or operate this product with wet hands.
5. Do not touch the high-temperature panel or the main head to avoid scalding.
6. Do not touch the machine's panel if it is damaged while the product is powered on.
7. Do not install or remove attachments while the product is in use.
8. Do not direct steam toward people, plants, or pets to avoid the risk of burns.
9. Do not operate the steam function without water in the tank to prevent damage to the pump.
10. Do not leave the product unattended while it is in operation.
11. Unplug the power cord before adding water or cleaning the product.
12. When unplugging, hold the plug firmly and do not pull on the power cord.

Filling the Water Tank

1. To add water to the tank, gently press the water tank and rotate counterclockwise until it is placed in the unlocked position. The tank will pop up slightly. Pull the water tank out of the unit, open the water tank cover, and fill it with water.




2. To extend the lifespan of the product, use pure or distilled water.



3. Close the water tank cover securely to prevent leakage, then insert the water tank back into the unit until it is properly seated.

4. After filling the water tank, refer to the illustration below for correct installation.



Operation Instructions

1. This product does not have a power switch. The heating indicator turns on automatically when the unit is plugged in. After approximately 25 seconds of preheating, the handheld steamer is ready for use.
2. When the indicator light turns on after the plug is inserted into the power socket, it means the product is powered on and preheating.
3. Once the heating indicator light remains on, preheating is complete, and the steamer can be used. For first-time use, it is recommended to wait at least 35 seconds before steaming clothes.
4. During first use, a small number of water droplets may appear near the steam outlet on the heating panel. This is a normal phenomenon.
5. Press the steam button to activate the water pump and release steam. Steam is released through the steam outlet when the steam button is pressed and held.
6. After ironing, it is recommended to run the device briefly to pump out any remaining water. Then hang the unit using the hanging loop for storage.
7. Unplug the product from the power supply after use.

Cleaning Guide

1. Do not immerse the product in water or any other liquid for cleaning.
2. Do not add vinegar, dishwashing liquid, saline solution, or any other chemicals to the water tank.
3. Do not use steel scrubbers or abrasive cleaning agents on the product.
4. After the appliance has completely cooled down, clean it with a damp cloth and a non-corrosive liquid cleaner. Pay special attention to removing dirt and scale from the steam nozzle.

Steaming Tips

1. To prepare your fabric for steaming, brush it with the soft cushion brush

attachment. This helps loosen the fibers and allows better steam penetration. Hang the garment or fabric before steaming.

Note: Avoid using metal clothes hangers if possible.

2. Hold the steam jets just above the fabric where wrinkles are present. It may take several passes to remove wrinkles completely.

3. After use, unplug the steamer and empty any remaining water from the tank to prevent leakage.

Caution: When hanging garments on a door while steaming, be careful to avoid damaging the door with steam.

4. Before steaming, first test the unit on an inconspicuous area of the item to be steamed. Use the LOW setting to ensure the fabric can tolerate the effects of steam. If no damage is observed, you may proceed to use the steamer on the item.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**