

PORODO



Porodo

MALIBU

Selfie Stick with Tripod

SKU: PDI10WH



Table of Contents

Product Overview	2
Specifications	2
Product Diagram	3
Usage Guide	4
Battery Replacement	4
Safety Precautions	5
Bluetooth Pairing	5
Recording Instructions	6
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo Malibu Selfie Stick with Tripod is a versatile and compact accessory designed for capturing the perfect shots. It features a 680mm extendable pole for adjustable height, allowing for a wide range of shooting angles. The stick's stable tripod ensures a steady base for selfies, group photos, and videos. With Bluetooth V5.4 connectivity and a built-in remote controller, you can effortlessly take photos or videos from a distance. The aluminum alloy rod provides durability and strength, while the design allows for easy compact storage, making it an ideal travel companion for photography enthusiasts.


Specifications

Material	ABS + Aluminum Alloy + Zinc Alloy
Battery Capacity	50mAh (CR1225)
Extended Width	680mm
Clamp Width	95mm Max
Wireless Range	10m
Bluetooth Version	5.4
Working Temperature	-10°C to 40°C
Device Compatibility	Android, iOS
Product Weight	139g
Product Size	30 x47 x 125mm

Model Number	PDI10
--------------	-------



Product Diagram

- 1.It features a variety of inflation modes, each automatically setting an appropriate pressure value.
- 2.The preset tire pressure and real-time tire pressure are displayed simultaneously for easy monitoring.
- 3. A real-time power reminder alerts users when the remaining battery is low.
- 4. Automatic delay shutdown ensures energy efficiency.
- 5. A selection of air nozzles is available for different inflation needs.



Reminder: Please make sure to peel off the battery insulation before use.

1. Slide the remote out from the left side.




2. Peel off the battery insulation film.

Usage Guide


1. Hook the groove at the base of the tripod and pull out each of the three legs.

2. Flip the tripod open until it is fully uploaded, as shown in figure 4.


NOTE: Do not press down forcefully when using the tripod to avoid damage and extend its lifespan.




1



2



3



4

Battery Replacement

Use a small screwdriver to remove the screw on the remote's back cover and replace the battery. The standard battery type for this product is CR1225 button battery.

Tip: Insert the new battery in a way that the positive terminal faces outward.

Safety Precautions

1. This product contains button batteries. Swallowing them may cause chemical burns and severe internal damage within two hours, potentially leading to more serious health consequences.
2. Keep both new and used batteries away from children. If you suspect that a button battery has been swallowed or inserted into any part of the body, seek immediate medical attention.
3. Always ensure the selfie stick is fully extended and securely locked before use to prevent accidents or damage.
4. Do not use the selfie stick in high winds or unstable conditions, as this may cause it to topple over or become difficult to control.
5. Keep the Bluetooth remote control away from water or moisture to avoid damage.
6. Do not place heavy objects on the tripod or extend the pole beyond its maximum capacity to prevent the selfie stick from breaking or becoming unstable.
7. Avoid using the selfie stick while driving or in moving vehicles to prevent distractions and ensure safety.
8. Keep the selfie stick and tripod away from children or pets to avoid injury.
9. Store the selfie stick in a dry, cool place when it is not in use to preserve the materials and functionality.
10. Regularly check the stability of the tripod and the connection points of the selfie stick for wear and tear.
11. Use the selfie stick only with devices that are within its weight and size specifications to avoid damage to both the stick and your phone.
12. Avoid using the selfie stick near electrical equipment or power sources to minimize the risk of electrical hazards.

Bluetooth Pairing

For first-time pairing, press and hold the camera button for 2 seconds. The

blue light will flash, indicating that the device is in pairing mode. Turn on your phone's Bluetooth function in the settings, search for the device named "Mini Selfie," and click to pair. The blue light will turn off once the device has paired successfully.

Recording Instructions

After completing the Bluetooth pairing, open your phone's camera and press the camera button to take photos or record videos. If there is no operation, the device will automatically turn off after 300 seconds. To turn it back on, press the camera button once, then press it again to take a photo.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**