

PORODO



Porodo Gaming

ARCADE Pro Classic JELOS OS HD

Display Game Console with
28 Emulators & 20000+ GAMES

SKU: PDX634


Table of Contents

Features	2
Product Overview	2
Initial Setup	3
Function Introduction	3
Charging Instructions	3
Specifications	4
Warranty	5
Contact Us	5

Features

1. The device boasts an ergonomic controller-like design for intuitive use.
2. Includes a high capacity 5000mAh battery for prolonged use.
3. Features a 4" HD display screen, offering clear and vibrant visuals.
4. Equipped with a high-performance quad-core CPU, ensuring smooth gameplay at 60 FPS.
5. Incorporates an independent dual TF card system for game storage, enabling system upgrades without the need to copy games.

Product Overview



Initial Setup

The instructions for starting and shutting down the gaming console are as follows:

A. Starting the Console

1. Insert the System Card and the TF-GAME Installation Game Card.
2. Press the power button for 3 seconds to boot the system.

B. Shutting Down the Console

Press the SELECT button to initiate shutdown.

C. Sleep Mode and Forced Shutdown:

1. Press the power button briefly to enter sleep mode.
2. Hold the power button for 10 seconds to force a shutdown.

Function Introduction

Button	Function
Power	Power On/Enable Sleep Mode
SELECT	Restart/Power Off
START	Settings/Adjust Brightness/Set Language/Adjust Volume
SELECT+START	Quit the Game
SELECT+UP/DOWN	Adjust Volume
SELECT+L1 R1	Save/Shortcut the Game
SELECT+LEFT/RIGHT	Save Location
SELECT+R2	Speed Up the Game
SELECT+X (L3+R3)	Game Settings

Charging Instructions

1. Initial Charge: If the device is being used for the first time or the battery level is low, charge it using a 2A charger connected to the USB docking port for at least 30 minutes before use.

2. During Operation: In case the battery level indicates zero and the indicator flashes a red light, this means the battery level is low and needs to be charged instantly.

3. Indicator Light Guide

Indicator Light Color	Description
Green	Device is operating normally.
Red	The battery level is low/The device is being charged.

Specifications

Product Name	Porodo Gaming ARCADE Pro Classic JELOS OS HD Display Game Console with 28 Emulators & 20000+ GAMES
SKU	PDX634
Battery Capacity	5000mAh
input	5V/2A
Recharge Time	2.5h
Playtime	Up to 10h
System	Multiple Open-Source Linux
Game Compatibility	Multiple simulators (MAME, N64, PS, CP3, NEOGEO, GBA, NES, SFC, MD, NDS)
Display	4" IPS
Resolution	720×720
Processor	ARM Quad-Core 1.8GHz
RAM	1GB LPDDR4
Storage	TF Slot 16 1 GB (Included)/TF Slot 128 2 GB (Included)
Connectivity	Wi-Fi 2.4GHz, Bluetooth, HDMI
Interface	USB, 3.5mm Audio Jack

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**