




Product Parameters

Material: ABS Rubber Oil + Cloth Mesh
Charge Port: Type-C
Output Power: 4Ω, 5W
Charging Voltage: DC 5V/1A
Battery: 1200mAh Battery
Battery Operation Time: 4 hours on a full charge.

Product Diagram



1. LED Indicator Light
2. Volume Button (+) / Next Track Button
3. Power Button: Turn On/Off, Play/Pause Music
4. Volume Button (-) / Previous Track Button
5. TF Card Port
6. DC 5V Charge Port
7. 3.5mm Audio Port
8. Silicone Cover
9. Strap Attachment Point

How to Use

1. Power Button: Long press to switch the speaker on or off. A short press toggles play or pause.
 2. Volume Control (+): Hold to increase the volume, or press briefly to skip to the next track.
 3. Volume Control (-): Hold to decrease the volume, or press briefly to return to the previous track.
 4. Audio Input: Connect a 3.5mm audio cable to the AUX port, and the speaker will automatically enter Audio Mode.
 5. Micro SD Card Slot: Inserting a Micro SD Card switches the speaker to SD Card Mode, supporting various audio formats such as MP3, AAC, WAV, FLAC, APE, and WMA.
 6. Charging Port: Use to charge the speaker.
 7. Charging Indicator: A red light indicates charging is in progress. The light turns off when the speaker is fully charged.
 8. TWS Function: For stereo sound, turn on two speakers, pair them by double-clicking the (+) button. Connect your device via Bluetooth to enjoy music. To disconnect TWS pairing, double-click the (+) button again.
- *Bluetooth Name: ST-Clap

Note: The battery's lifespan is contingent on the volume and usage patterns of the music played.

Caution

- *Avoid installing the appliance in confined spaces, such as bookcases or built-in cabinets.
- *Do not expose batteries (whether a battery pack or individual batteries) to prolonged high temperatures, such as direct sunlight or fire, nor to extreme low temperatures that

could lead to overheating or thermal runaway.

*Do not attempt to dismantle, open, or shred the batteries. In case of battery leakage, prevent the liquid from coming into contact with skin or eyes. If contact occurs, immediately flush the affected area with plenty of water and seek medical advice.

*Secondary cells and batteries should be charged prior to initial use.

*Always utilize the designated charger and consult the manufacturer's instructions or equipment manual for proper charging guidance.

*If the batteries have been in storage for an extended time, it may be necessary to perform several charge and discharge cycles to achieve optimal performance.

*Dispose of the batteries in accordance with appropriate regulations.

Others

*Avoid using or storing the unit in extreme temperature conditions, outside the safe operating range of 5°C to 35°C (41°F to 95°F). If the unit is operated or left outside of this temperature range, it may automatically shut down to safeguard its internal circuitry. At high temperatures, charging may cease, or the volume may automatically lower to prevent battery damage.

*Even if the unit is not intended for regular use, charge the battery fully every six months to maintain its performance.

Contact Us

If you have any questions about this Privacy Policy, please contact us at: info@porodo.net
Website: porodo.net
Service Support: support@porodo.net
Instagram: [porodo](https://www.instagram.com/porodo)