



## PRODUCT FEATURES

- Bluetooth Version: 5.3
- Voice Assistant Compatibility: Siri
- Touch Control: Music play/pause, next/previous track, volume +/-, accept/end/reject calls, voice assistant
- Charging Interface: USB Type-C
- Pocket-Friendly/Lightweight Case

## TECHNICAL SPECIFICATIONS

|                     |                       |
|---------------------|-----------------------|
| Bluetooth Version   | 5.3                   |
| Support             | A2DP, AVRCP, HSP, HFP |
| Bluetooth Frequency | 20Hz-20kHz            |
| Bluetooth Range     | 15m                   |
| Earbuds Battery     | 180mAh                |
| Charging Time       | 1.5-2h                |

## PACKAGE CONTENTS

The product includes the following items.  
If any items are missing, please contact us immediately.

| S/N | Items                      | Qty |
|-----|----------------------------|-----|
| 1   | True Wireless Earbuds Unit | 1   |
| 2   | USB Type-C Charging Cable  | 1   |
| 3   | User Manual                | 1   |

## BEFORE FIRST USE

BEFORE FIRST USE  
For an optimal experience,  
please charge the charging case  
and earbuds before using them  
for the first time.



## BEFORE FIRST USE

- When charging the case, the LED indicator will flash red.
- When the case is fully charged, the LED indicator will stay red.



## BEFORE FIRST USE

For an optimal experience, please charge the charging case and earbuds before using them for the first time.

## OPERATING INSTRUCTIONS

### Skipping to the Previous Song

Tap the Multi-Function Button (MFB) on the left earbud 3 times.

### Skipping to the Next Song

Tap the MFB on the right earbud 3 times.

### Playing/Pausing a Song

Tap the MFB once on either earbud to play or pause the music.

### Increasing/Decreasing Volume

Increase volume: Tap the MFB on the right earbud 2 times.  
Decrease volume: Tap the MFB on the left earbud 2 times.

### Rejecting a Call

To refuse an incoming call, press and hold the MFB on either earbud for 2 seconds.

### Answering/Ending a Call

Tap the MFB once on either earbud to answer or end a call.

### Activating Voice Assistance

To use Google Voice Assistant or Siri, press and hold the MFB on either earbud for 2 seconds.

Note: Control functions may vary depending on the connected device.

## SAFETY INSTRUCTIONS

1. Store earbuds in a dry and well-ventilated area to prevent contact with oil, steam, moisture, dust, etc., and to maintain optimal product performance.
2. Refrain from using harsh organic solvents or items containing these substances for cleaning the earbuds.
3. Use the earbuds as intended and follow the standard operating procedures. Be mindful of the environmental impact and maintain a connection distance of no more than 10 meters between your phone and earbuds for the best performance.
4. If the earbuds experience issues such as poor connectivity or compromised communication, do not attempt to disassemble them. Unauthorized repairs or modifications could void the warranty.
5. Use only a standard or manufacturer-approved car charger or charging cable to recharge the earbuds.
6. To maintain the earbuds' functionality, ensure they are adequately charged.