

porodo | CHOOSE THE BEST



10000mAh



Slim Powerbank

Built-in Lightning and Type-C

Model: PD-PBFCH029-BK

Product Introduction

Thank you for using our company's products! This product is a portable charging device that can charge digital products such as mobile phones, tablets, e-books, and game consoles. It uses high-quality lithium-ion polymer batteries and charging and discharging chips, etc. Bring you valuable experience



Basic Specification

Model:PD-PBFCH029

Battery:Li-Polymer

Battery Powe:38.5Wh 3.85V 10000mAh

Rated Capacity:5200mAh (5V/3A)

Input:Type-C

Output:USB-A Type-C cable Lightning cable

Type-C Input: 5V---2A 9V---2A(Max)

USB-A Output: 5V---4.5A 4.5V---5A 5V---3A

9V---2A 12V---1.5A(Max)

Type-C cable output: 5V---4.5A 4.5V---5A 5V---3A

9V---2A 12V---1.5A(Max)

Lightning cable output:5V---2.4A 9V---2.22A (Max)

Product size:~110*68*16mm

Weight:~180g

Packing List

Power bank*1

User Manual*1

USB cable*1


The specific accessories are subject to the actual product

Power Capacity LED Indicator

Press on/off button to see remaining power capacity.

One indicator light represents 25% of the power, and 4 lights are always on to indicate that the battery is fully charged. In the scene of charging the mobile power supply, the indicator light will blink, and if it enters the fast charging mode, the indicator light will turn green. When the mobile power supply is charging other devices, the indicator light is always on, and if it enters the fast charging mode, the indicator light turns green

charging the mobile power supply	
LED INDICATOR	LED Quantity
One LED is on	●○○○
Two LED are on	●●○○
Three LED are on	●●●○
Four LED are on	●●●●




mobile power supply is charging other devices			
LED INDICATOR	LED Quantity	Corresponding power ratio	Remarks: When discharging, the LED lights will decrease in turn due to the reduction of power. When the remaining power of the product is lower than 5%, the last LED light will not flash with the short press of the button.
Fluctuating light	○○○○	0~5%	
One LED is on	●○○○	5%~25%	
Two LED are on	●●○○	25%~50%	
Three LED are on	●●●○	50%~75%	
Four LED are on	●●●●	75%~100%	

Instructions

Charge the power bank

One end of the charging cable is connected to the charger, and the other end is connected to the mobile power supply. When the indicator light flashes, it indicates that it is in the charging state.

When the mobile power supply encounters abnormal conditions such as overcharge and overdischarge, it will automatically enter the protection mode. At this time, the mobile power supply stops working. If you need to reactivate the mobile power supply, you can recharge the mobile power supply.



It is recommended to use a fast charging charger for a better charging experience.


Instructions

To charge the phone

One end of the charging cable is connected to the output port of the mobile power supply, and the other end is connected to the mobile phone that needs to be charged. The indicator light of the mobile power supply is on, and it enters the external charging state.

When the mobile power supply encounters abnormal conditions such as overcharge and overdischarge, it will automatically enter the protection mode. At this time, the mobile power supply stops working. If you need to reactivate the mobile power supply, you can recharge the mobile power supply.

Charge other digital devices One end of the charging cable is connected to the output port of the mobile power supply, and the other end is connected to the digital device (such as a tablet, etc.) that needs to be charged.



Safety Information

Improper use may lead to battery failure, severe heat, or even fire and explosion! In order to avoid personal injury and property damage, please strictly follow the following requirements to store and use this product:

- This product is not a toy, please keep it out of the reach of children, and prohibit children from using or playing with it to avoid accidents.
- Be sure to choose a charger that complies with local safety standards (such as China's 3C certification standard) to charge this product to prevent electric shock or battery damage.
- Do not press or hit the product heavily, and avoid severe drop or strong vibration of the product. If these situations occur, or liquid seeps/splashes into the product, it may cause damage to the product. If the battery or circuit is damaged or short-circuited, please stop using it immediately and dispose of it properly.
- If the product is bulging, deformed, leaking, or the capacity is obviously reduced, please stop using it immediately and dispose of it properly.

- Do not place this product in pockets, airtight packages, beds, sofas and other places that may affect its heat dissipation or discharge it to the outside, and make sure that the product during use is not covered by clothing, pillows, bedding or other miscellaneous objects, etc.
- It is strictly forbidden to disassemble, squeeze, puncture, short-circuit this product or throw it into water or fire (including near heat sources such as stoves and radiators) or expose it to environments with temperatures higher than 60°C (140°F).
- When the weather is hot, please do not place this product in an unmanned car or other places exposed to sunlight.
- This product contains a lithium polymer battery. It is strictly forbidden to disassemble the product case without authorization to avoid possible damage to the battery or other dangers..

Precautions

- For the first use, please fully charge this product.
- When charging this product or using this product to charge other devices, please choose a suitable charger and data cable by yourself (it is recommended to choose a charger and data cable of a big brand).
- When charging this product, please ensure that someone is present, and please unplug the power supply when going out or leaving for a long time.
- After this product is fully charged or this product is fully charged to other devices, please remove the connection line in time to avoid loss caused by long-term connection.
- If the product has no battery indicator after pressing the button, it may be in a protection state, and an external charger can be connected to try to restore it.
- When the product is not used for a long time, please keep the power of the product at about 50% and store it in a cool and dry environment. Avoid long-term storage of this product in a state of full power or no power, to extend battery life.

Note: The illustrations of products, accessories, user interface, etc. in the manual are schematic diagrams. for reference only. Due to product updates and upgrades, there may be slight differences between the actual product and the diagram, and the actual product shall prevail.