




Port Function:

1. Volume +, Next Track
2. Power ON/OFF, Play or pause music, answer or end calls, and switch between gaming and music modes.
3. Volume -, Previous Track
4. USB Charging Port
5. 3.5mm Jack
6. Indicator Light
7. Microphone Hole

Thank you for your purchase and for choosing our Wireless Bluetooth earphone.

To ensure you have a safe and enjoyable experience, please read this manual thoroughly and keep it for future reference.

A. Product Description:

1. Bluetooth version 5.3+EDR for enhanced wireless connectivity.
2. Supports making calls and playing music via Bluetooth.
3. Contains a lithium-ion battery that charges via a Type-C cable.
4. Offers language support for English and Chinese.
5. Features intelligent power-saving technology that automatically powers off if not paired within 5 minutes.

B. Product Specifications:

1. Maximum working range in an unobstructed space: 15 meters.
2. Frequency response range: 20Hz to 20kHz.
3. Sensitivity: 3±82dB.
4. Impedance: 32Ω.
5. Speaker diameter: 40mm.
6. Charging time: approximately 2 hours.
7. Rated output power: 20mW.
8. Battery life during playback (LED off): approximately 66-64 hours.
9. Battery life during playback (LED on): approximately 17-15 hours.
10. Talk time with LED off: 40-38 hours; with LED on: 15-13 hours.

C. Product Instructions:

Wireless Bluetooth Functionality:

1. Pairing Method:

- Press/hold the power key for 2 seconds until the red and blue LEDs flash alternately, indicating pairing mode.
- On your Bluetooth device, search for and select the model name 'ST-KidsV2'.
- A successful connection is indicated by a steady blue light. The headphone will reconnect automatically to previously paired devices.

2. Music Playback and Call Handling:

- Press the power key once to play music. Press again to pause.
- To answer a call, press the power key. Press again to end the call.
- To reject an incoming call, double-press the power key.
- Double-click the power key to toggle between gaming mode and music mode.




-To skip to the next track, long-press the "+" button.

A short press increases the volume.

When the maximum volume is reached, you will hear a "didi" sound.

-For the previous track, long-press the "-" button.

A short press decreases the volume.



-Press and hold the "O" button for 2 seconds to turn on the headphones.

After they are connected, a 2-second long press activates the voice assistant.

Press both "+" and "-" for 3 seconds to turn off the device.

-The "O" button also switches to AUX mode when a 3.5mm jack is used.

Connect the AUX cable to your mobile phone or computer to switch off Bluetooth and enter AUX mode.

3. Charging Function:

-To charge the headset, connect the USB to an adapter or computer. The red LED indicates charging and turns off when the battery is full.

The headset will automatically power off and cannot be turned on while charging.

-An audio prompt will notify when the battery is low.

D. Package Contents:

- Earbud * 1
- Charging Cable * 1
- User Manual * 1

E. Cautions:

-Avoid using the product in damp, dusty, or smoky environments, and do not expose it to direct sunlight.

Also, do not leave it in a vehicle for a long time as it may cause damage.

-Listen at a reasonable volume to avoid hearing damage. Avoid using the headphones while driving or cycling.

-Clean the product with a soft dry cloth.

-Do not use the headphones during a thunderstorm.

-Keep the headphones away from water; they are not waterproof.

-Always use a certified charger with DC 5V output or a USB-enabled PC and charger.

F. Kindly Reminder:

For any questions not covered in the manual, please contact your local dealer.

Battery Usage Safety Warning:

- Do not expose the battery to extreme heat, puncture, or fire.
- Avoid placing the product in high-temperature environments.
- Do not use if the product has been submerged in water.