



Lune
AIR CONDUCTION TWS
SKU:PD-STWLEP021-BK

EARPHONE DISPLAY



ACCESSORIES INCLUDED

QUANTITY	ITEM
1	Earphone Set
1	Signature Packaging Box
1	Fast-Charge Cable
1	Comprehensive User Guide

BLUETOOTH CONNECTIVITY GUIDE

- Simply open the charging compartment, and the earphones will power on, ready to connect. They are designed to intuitively enter the pairing mode.
- Initiate a connection search "PD-STWLEP021" on your device to link up.
- For most modern phones, no password is needed. However, if prompted, input "0000". Once connected, you'll hear a voice prompt, ensuring you're set to enjoy calls and music seamlessly.

BLUETOOTH PAIRING GUIDE

- The headphones retain previous connections. When powered on, they'll prioritize reconnection to the last paired device. If that's unavailable, they'll be ready for a new pairing.
- If not connected within 30 seconds, the headphones enter the default pairing mode. During this, the main earpiece shows alternating red and white flashes, while the auxiliary light remains steady. If pairing isn't completed in the next 3 minutes, they'll automatically shut off to save battery. Also, a lack of connection for over 30 seconds initiates the loopback mode, causing the earpiece to flash in the same pattern until connected.
- Once successfully paired, the LED indicates this with a brief light-up.

BASIC USAGE GUIDE

- Power On:** Simply open the earphones, and they'll power up, indicated by a one-second white flash.
- Pairing:** Press and hold the "touch button" for 3 seconds when outside the charging box. You'll see a white flash, signaling readiness.
- Power Off:** Place the earphones back into the charging box. They'll auto-shutdown and initiate charging. If left unpaired, they'll turn off after 3 minutes for energy efficiency.
- Emergency Off:** If they're somehow not responding, press and hold the touch button on both earphones for 5 seconds. They'll reset and power off.
- Volume Control:** A quick tap on the right ear's touch button increases the volume, and the left decreases it. These adjustments don't trigger any light indicators.
- Media Control:**
 - Play/Pause:** A double-tap on the touch button.
 - Answer/End Call:** Double tap during an incoming call or ongoing call.
 - Decline Call:** When receiving a call, press and hold the touch button for 2 seconds to reject.
- Track Navigation:**
 - Previous Track:** Three taps on the left ear's touch button.
 - Next Track:** Three taps on the right.
- Voice Assistant Activation:** Press and hold either earphone for 2 seconds.
- Switch Modes:** Press the right earphone for 2 seconds to switch between game mode and music mode.
- Factory Reset:** Quickly tap either earphone five times to reset and disconnect.

PRODUCT DETAILS

Bluetooth Version: V5.3	Sensitivity: 95dB	Playback Duration: 9 hours	Charge Duration: Less than 2 hours
Impedance: 20 ohms	Power Rating: 10mW	Standby Duration: 240+ hours	Bluetooth Range: Up to 10 meters


CHARGING GUIDELINES

- A low battery alert will be signaled when the earphones are nearing depletion. This warning is activated every 1 minute, and is denoted by a rapidly flashing red light.

- Upon inserting the earphones into the charging case, the red indicator will remain illuminated for an extended period, turning off once a full charge is achieved.

- Before initiating the charging process, ensure the earphones are powered off and connect to a trustworthy power outlet.

Note:
It's essential to maintain the cleanliness and integrity of the USB charging port to ensure efficient charging.



CARE & STORAGE RECOMMENDATIONS

- Storage: Allocate a cool, dry area for safekeeping.
Optimal Usage Conditions:
- Operate within a temperature range of 5-45°C. Exposing the earphones to extreme cold, heat, or prolonged sunlight may compromise battery longevity and overall performance.
 - Avoid usage during thunderstorms.
 - After extended periods of inactivity, ensure the earphones are charged prior to use.
 - To clean, gently wipe with a lint-free cloth, especially if moisture or sweat is present. This ensures consistent functionality.
 - Keep the earphones away from sharp objects or materials that might cause damage.

Warranty Statement

Disclaimer:
This user manual does not offer any explicit guarantees, claims, or representations. The products, specifications, and information provided are for reference only. Contents may be updated on our website periodically.

Warranty Details:
This product is guaranteed as follows: If any defects arise within 12 months from the date of purchase (referred to as the "Warranty Period"), it will be repaired or replaced at no additional cost. If the product cannot be repaired, and the manufacturer confirms this, a replacement will be provided. The user should continue to avail the benefits of the warranty for the entire duration. If the product was purchased on sale, the shorter of the two periods will apply; however, the warranty shall not be less than 30 days. The warranty period will be 13 months if the exact purchase date cannot be determined. Before making a warranty claim, please contact our product service hotline and follow the procedures instructed by our team. When applying for the warranty, ensure you present a complete purchase receipt or valid sales invoice.

Exceptions to the Warranty:
The warranty does not cover the following situations:
-If the product is used beyond its validity period or the three included packs.
-If the physical appearance of the used product does not match its original structure.
-Damages caused by misuse, abuse, improper transportation, handling, maintenance, or external obstacles.
-Damage resulting from force majeure events such as earthquakes, wars, or other unforeseen catastrophic events.
-Damages to the zipper or buckles caused by undue force.
-Disconnections caused by an excessive load.
-Any damage by sharp objects.
-Evidence of flooding or burning.
-Products displaying unauthorized disassembly.
-Signs of discoloration, abrasion, rupture, or other damages occurring during the normal use of the product.
-Altering or damaging the original identification label of the product.

Limitations:
While we ensure the completeness and quality of the product and its accompanying materials, some aspects may not be covered under this warranty. We recommend inspecting the product upon purchase.

General Provisions:
-The above guarantees are the only warranties we provide for our products.
-They are applicable within all legal parameters, ensuring consumers are not deprived of any rights that are protected by law.