

porodo
LIFESTYLE



Portable Outdoor
Illuminated Folding Seat

SKU:PD-CTLDST

Lighting Features:

(Note: Applicable only for the stool with a lamp)



Constant Light: Activate continuous light that supports up to 24 hours by pressing the button once.



Breathing Light: Press twice for a slow-pulsing light, which supports 4 hours of illumination.



Warning Light: Press thrice for a rapid-blinking red light, designed for emergency signaling, supporting 4 hours of illumination.


Product Information:

Material	Durable Engineering PP
Folded Size	cm height 6.5
Unfolded Size	cm height 42
Stool Diameter	cm 26.2
Weight	kg 1.11
Load Capacity	Up to 200 kg



QR Code: Scan to access a video tutorial for detailed operational guidance.

Applications:



Perfect for travel, fishing, and camping activities.

Usage Instructions:



1. Unlocking: Open the buckle to release the stool.



2. Opening: Grasp the designated openings on both sides to unfold.



3. Expanding: Pull two ends to extend the stool.



4. Adjusting: Stretch to the required height and twist to lock in place.



5. Locking: After using, unlock by pulling and rotating to the end, allowing free retraction.



6. Closing: Push the stool together and secure it with the buckle.



7. Battery Access: Open the battery cover latch for compartment access.



8. Battery Replacement: Turn counterclockwise to open and expose the battery compartment.



9. Battery Installation: Insert two AA batteries following the correct orientation.

Cautions:

- Avoid hitting the side of the stool to prevent damage.
- For stability, do not sit sideways on the stool.