



PRODUCT DETAILS

Features

- Bluetooth Version 5.1+EDR
- Voice Assistant Compatible (Google & Siri)
- Touch Control—Music Track, Volume +/-, Calls & Voice Assistant
- Type-C
- Splash & Sweat Resistant
- Pocket Friendly & Lightweight Case
- 5 Hours Playback with Single Charge
- 15 Hours Playback with the Case
- High-Quality Microphone
- 13mm Dynamic Drivers

Technical Specifications

Bluetooth version	5.1+EDR
Support	A2DP, AVRCP,HSP, HFP
Bluetooth Frequency	2.4GHz
Bluetooth Range	10m
Earbuds Battery	25mAh
Charging Case Battery	300mAh
Charging Time	1.5h

KNOW YOUR PRODUCT

Package Contents

This package contains the items listed below. In case any of the listed items are missing, immediately contact us.


Understanding True Wireless Earbuds

S/N	Items	Qty
1	True Wireless Earbuds Unit	1
2	USB Type-C Charging Cable	1
3	User Manual	1

Multi-Function
Button (MFB)

Earbud
Charging Point

Type-C
Charging Point



Operating Your Earbuds

Initial Setup



Before you start, ensure that both the earbuds and the charging case are fully charged for an optimal experience.

Charging Indicators

- The case's LED blinks red while charging.
- When fully charged, the red LED stays lit.



Bluetooth Pairing Process

- The earbuds automatically engage in pairing mode when taken out of the case for a seamless connection.
- Ensure your device's Bluetooth is on to find and connect to the earbuds.

Track Navigation

Skip to the Previous Track:

Long-press the MFB on the left earbud.



Skip to the Next Track:

Long-press the MFB on the right earbud.



Volume Adjustment

Increase Volume: Single tap the MFB on the right earbud.



Press 1 Time
Volume Down Volume Up

Decrease Volume: Single tap the MFB on the left earbud.
Call Management



To Decline an Incoming Call:

Long-press the MFB on either earbud.



Long Press

Music Playback

To play or pause a song:

double tap the Multi-Function Button (MFB) on either earbud.



Call Handling

Answer a Call: Tap the MFB on either earbud once.



Hang Up

Double tap the MFB on either earbud.



Voice Assistant Activation

Access Google Voice Assistant or Siri by triple-clicking the MFB on either of the earbuds.



Triple-click

Note: Control functions may vary based on the connected device.

Safety Guidelines

A. General Precautions

- Inspect the product for any damage or odd smells before use and avoid using if any are detected.
- Store the earbuds in a dry, well-ventilated area to prevent damage from oil, water, moisture, and dust.
- Refrain from using volatile organic compounds to clean the earbuds

B. Product Usage

- Follow the specified guidelines to mitigate environmental impacts on the earbuds' performance.
- Keep your device within 10-15 meters of the earbuds to maintain a stable connection.
- Disconnect the product from power once fully charged, especially if not in use for prolonged periods.
- Avoid using non-specified accessories which could lead to malfunctions and void the warranty.

C. Maintenance and Repair

- Do not attempt to service or repair the earbuds yourself to prevent the risk of electric shock or voiding the warranty.