



ICE CREAM MAKER

Model: PD-BLICM-WH

Please read the instruction manual carefully and follow the instructions for operation and use before using this product. Pls keep the manual for future reference. This product is for home and similar use only

Precautions (Juicer)

1. This product with lithium batteries to drive DC motor work, chargers using 5V/1A adapter, please use the provided USB power cord to fully charge the product before use, charging time should be 3 hours or above. Also, clean all parts that contact with the food and dry it before use.
2. Remove the main body or cup only after the product has been switched off and the knife has stopped working completely.
3. When cleaning the product, make sure that the switching power is off and the charging port silicone is plugged in before cleaning the main body and cups. Do not immerse the main body into water or other liquids, nor flush the main body under water or other liquids.
4. Do not use the product to make juice more than 5 times one time continuously to avoid overheating caused by heavy electronic component loads.
5. This product has overload protection function, if size of the ingredients too big and block the knife, the product will stop working, accompanied by "beep" sounds for three times, after removing the overload ingredients it can be restarted again.
6. Each accessory of this product cannot be disinfected by hot water or microwave ovens exceeding 60 degree Celsius to protect it against thermal deformation.
7. Do not put the main parts of the appliance into the dishwasher or cleaning equipment, and do not use steel velvet, abrasive cleaners or corrosive liquids to clean the product.
8. This product is for special fresh juicer, it is not suggest to winch meat, ground nuts or soy products.
9. Permanently disconnect the blender before assembling, disassembling or

cleaning:

10. Turn off the power switch and disconnect the power supply before replacing the accessories or touching moving parts.

11. The product has a built-in lithium battery and the following things to be noted:

A. Do not use this product for a long time, please charge every three months to prevent battery damage; B. Charge when the battery electricity is low.

12. This product is for domestic use only. Please follow the instruction manual to avoid any unnecessary damage.

* Fully charge the product before first using it and thoroughly clean the parts that contact with the food, this product have dual safety measures, only the cup body rotated to a fixed corresponding body position is in standby status (after rotating in place, the product "beep" sounds shows a prompt installed in place)

Instruction of use (Juicer)

1. Reread the previous notes. 2. Wash the fruit and cut it into small pieces of about 1.5 x 1.5cm (Note: fruit with core, hard material, thick skin or hard shell, remove it first);

3. the fruit fill into %60 of the maximum scale of the cup body is the best, and then add drinking water or

milk and other liquid to the maximum scale of the cup body, and then turn the main body to the cup, the buzzer "beep" a sound, to prove that the main body has been installed in place; Note: The fruit and water inside the cup cannot exceed the maximum scale of the cup body to prevent water or juice from overflowing.


4. Double-click to start the product, the product reverse (Picture 04), the default working time of the product is 40 seconds, gently shake the product when working, stirring effect is better;

5. After the juice is finished, wait for the blade stop working, and then reverse-clockwise rotation to remove the body, you can drink.

6. Plug the USB cable into the charging port (compatible a variety of 5V power

- supplies) when the appliance fails to start and the power LED flashes in red color;
This product can be connected to a variety of smartphone chargers with their own USB charging cable charging, but also can use charging treasure to charge the product, around 3 hours it will be full of electricity, fully electricity can make juicer around 11 cups.
7. Do not put the main parts of the appliance into the dishwasher or cleaning equipment, and do not use steel velvet, abrasive cleaners or corrosive liquids to clean the product.
8. This product is for special fresh juicer, it is not suggest to winch meat, ground nuts or soy products.
9. Permanently disconnect the blender before assembling, disassembling or cleaning:
10. Turn off the power switch and disconnect the power supply before replacing

Structure diagram



Technical parameters:

Product model	J1-01	Battery voltage	7.4V	Charging voltage	5V = 1A
Speed	18000rpm	Battery capacity	2*1500mAh	Rated power	55W
Stir capacity	340mL	Size	86*86*249(mm)		
Net weight	570g				



01 Place the protective cover on a slow-stirring side



15min 5min



02 (Install the body) rotates the body clockwise and tightens it on the juicing cup ("Beep" sounds).t





15min 5min



03 (Start making juicer) Double-click the juicer button to start the product (the working time is fixed at 40seconds, re-click the juicer button to stop the product from working).



04 (inverted product).

	
05 After the ingredients processing is completed, wait for the blade to stop working, and then reverse-clockwise rotation to remove the main body, you can drink.	06 The LED indicator is always on when working. A sufficient amount of electricity shows white light, and when there is insufficient power, shows red light, please charge it on time. When the product blade sticks, the product will stop working, accompanied by "Beep" sounds for three sounds, remove the ingredients of the blade restart it.
	
07 (charging) When charging, the LED indicator lights up at a constant red light After fully charged, the LED indicator will always be white (The product cannot start working when charging)	

Fault	Cause analysis	Troubleshooting
Cannot be powered on or shut down in using and has a red light flashing	There is not enough electricity	Please charge it in time
Stop working when using with three "Beep" sounds	product overload	Remove overload ingredients or cut into small pieces and reuse
Leaking	The main body and the juicer cup are not tightened	Tighten the main body with the juicer cup


Precautions (slow stirring)

1. Ice buckets are avoided under direct sunlight and put it away from heat sources such as heaters, stoves, etc. Do not use the product in uneven places.
2. Do not let children touch the frozen ice buckets to avoid frostbite.
3. Do not touch the frozen ice buckets with empty or wet hands, use gloves or cloth to touch it and avoid frostbite.
4. If coolant spills from an ice bucket, do not touch it with your hands or other parts of your body to avoid frostbite.
5. The console can only be used with the supplied product accessories, do not use other unofficial accessories to avoid malfunctions.
6. Do not take off the main unit while running, the mixing rod must not be exposed
7. The machine must not be used continuously more than 20 minutes, and if the using time exceeds 20 minutes, be sure to stop using it at least half an hour before using again.
8. This product is mainly for home use, it is not suggested for commercial use. Please follow the instruction manual to avoid any unnecessary damage.

How ice buckets are used

1. When freezing ice buckets, be sure to remove the host and freeze the ice buckets separately
2. When freezing ice buckets, be sure to keep the ice bucket openings facing up and vertically in the refrigerator freezer, and do not tilt and freeze the ice buckets upside down.
3. When freezing the ice bucket, be sure to wipe the water clean so that the blender bar does not rotate due to ice.
4. After use in a special ice bucket, be sure to liquefy the coolant in the ice bucket completely before placing it in the freezer to prevent uneven distribution of coolant. (Shake the ice bucket, if the liquid flows smoothly, you can freeze it again)
5. Do not break or fall on the ice bucket to avoid coolant spillage.
6. Use a plastic or wooden spoon to remove the finished ice cream from the ice bucket, do not use sharp cutlery and metal spoons to avoid injuring the surface of the ice bucket.
7. Do not place ice buckets in microwave ovens, ovens and other heat sources.

How ice buckets are used



Product model	Jl-01	Battery voltage	7.4V==	Charging voltage	5V == 1A
Slowly stir the speed	30-45rpm	Battery capacity	2*1500mAh	Rated power	55W
Slow-stir capacity	200mL	Size	96*96*216 (mm)		
Net weight	860g				




How to use


Ice buckets should be frozen around 10 to 12 hours below -20 degrees Celsius.
(Mechanical refrigerator please adjust the gear to be 5 gears or more to ensure the freezing effect)

For detailed instructions on ingredients, please refer to the accompanying recipe
Refrigerate the ice cream ingredients you want to make for 2-1 hours and make them more quickly (alcohol in the ingredients can affect the effect)

Do not stir until water is added, otherwise the mixing rod will not work

First put the ingredients in the juice cup and stir them well in a "juicer" operation

	
01 Place the protective cover on the juicing side (screw in clockwise and hear a "sound")	02 Load the blender bar into the main unit
	
03 Pour the stirred ingredients into an ice bucket, and the ingredients must not exceed the MAX line(200ml) (once the ingredients are placed in the ice bucket, immediately load the host into the ice bucket and start stirring to avoid freezing the ingredients and affect the stirring).	04 Place the host from top to bottom in an ice bucket

	Complete ice cream, please eat as soon as possible. If you want to save or store it, place it in the appropriate container and keep it in the refrigerator.
05 Double-click the slow-stir button, the machine starts working, at the same time, the 5min light flashes, you can click the slow-stir button to switch the stirring time (when the light flashes), flashing after the buzzer long drop, slow stirring timing officially began	06 When the operation is finished, the buzzer is long "Beep" sound for three times. Remove the console and remove the finished ice cream from the ice bucket.

During slow-cooking, such as the host followed up and down movement or left and right rotation, please turn off the power supply, the main body and the mixing rod out, using the included spoon, the ice bucket structure of the ingredients broken mix, again loaded back into the host and the mixing rod to continue operation.

The ice cream is softer, and if you want a harder taste, put the stirred ingredients in the freezer with the ice bucket and freeze for another 25-15 minutes.

Do not freeze ice buckets with ingredients for long periods of time to avoid damaging them.

FAQ Analysis

Fault	Cause analysis	Troubleshooting
Cannot be powered on or shut down in using and has a red light flashing	There is not enough electricity	Please charge it in time
The blender does not work	Whether the host and the blender bar are in place Whether the material in the ice bucket is frozen	Refit the main unit and the blender bar Check the material in the ice bucket
Ice cream is not made or works poorly	Whether the freezer bucket is frozen not Whether the ingredients are placed in the refrigerator to cool	Set the refrigerator to maximum gear and place the ice bucket in the freezer for more than 16 hours Leave the ingredients in the fridge for 1-2 hours before making