

porodo
LIFESTYLE

800ml



JUMBO BLENDER FOR JUICES & SMOOTHIES

MODEL: PD-P120JS-BK

Introduction:

Thank you for your patronage, welcome! In order for you to fully enjoy the services we provide, please browse the official website. The sports juice cup helps you squeeze the full nutritional value of fruit into a glass, so you can enjoy delicious and healthy juice every day. Innovative technology allows you to squeeze Take more healthy juice and quickly clean the product within 1 minute. Fully integrated design takes up less space for better juicing.

Precautions:

1. This product is a lithium battery that drives a DC motor. The charger is universal for all types of smart phone USB chargers. Please use it first.
2. The USB power cord provided by our company can be used after fully charging the product, and the charging time should be 4.5 hours or more. In addition, before use, please thoroughly wash and dry all parts that come into contact with food before use.
3. The lid can only be unscrewed after the product is turned off and the mixing knife has stopped completely.
4. When cleaning this product, please make sure that the switching power supply is turned off and the charging port is plugged with silicone, then clean the cup and the host. don't
5. The host is placed in water for cleaning to prevent water from entering the host and damaging electronic components.
6. This product is equipped with over-temperature protection. If the juice is squeezed continuously for more than 3-4 times, the product will be shut down for protection, and the red indicator light will flash Blinks 15 times, and it can be restarted after standing for 1 hour.
7. This product is equipped with overload protection function. If the knife is jammed due to the oversized food material, the product will be shut down for protection and accompanied by There is a red indicator light that stays on for 5 seconds, and it can be restarted after removing the ingredients stuck in the knife.
8. The accessories of this product cannot be sterilized with hot water over 60°C or microwave ovens to avoid thermal deformation and damage.
9. Do not put the main body parts of this product into the dishwasher or cleaning equipment, and no water can intrude into the main body.
10. Do not use steel wool, abrasive cleaners or corrosive liquids to clean the product.
11. This product is a special fresh juice machine, not suitable for grinding meat, grinding nuts or soy products.
12. Do not invert the product or start the product when the straw is still inserted into the main unit or the silicone plug of the water outlet is not plugged tightly.
13. If left unattended before assembly, disassembly or cleaning, always disconnect the power of the mixer; and unattended

Do not allow children to use the blender.

12. Be careful when taking out the mixing knife, cleaning the main unit and the mixing cup.

13. Turn off the power switch and disconnect the power supply before replacing accessories or touching moving parts.

14. This product is for household use only. If this product has been misused, for professional or semi-professional use, or if it has not been

If the operation is carried out according to the instructions, the warranty of this product will be invalid, and the company has the right to refuse the loss caused by it.
assume no responsibility.

15. Before disposing of the appliance, use a tool to pry open the case, and the battery must be removed from the appliance.

16. When removing the battery, the appliance must be powered off.

17. Batteries should be disposed of safely.

18. This product has a built-in lithium battery, please pay attention to the following:

a. Please store and use this product in an environment of 0-40°C;

b. If it is not used for a long time, please charge it every three months to prevent battery damage;

c. The charging speed may slow down in an environment lower than 10°C, which is a normal phenomenon;

d. Please charge it in time when the battery is low.

19. When discarding this product and product packaging, please hand it over to a department with relevant qualifications for recycling, and please cut off the power cord when discarding.

* Before using the product for the first time, fully charge the product before use, and thoroughly clean the parts that come into contact with food. This product has Double safety protection measures, only after the cup body rotates to the fixed position corresponding to the fuselage, it is in the standby working state.

Instructions for use:

1. Re-read the previous notes.

2. Wash the fruit and cut it into small pieces of about 1.5*1.5cm (Note: For fruits with core, hard material, thick skin or hard shell, please remove them first);

3. Put in the fruit, about 60% of the maximum scale of the cup is best, then fill up with water to the maximum scale of the cup, and then

Screw the host to the cup, the indicator light will flash once, which proves that the host has been screwed in place;

Note: The fruit and water placed should not exceed the maximum scale line on the cup body to prevent water or juice from spilling out.

4. After double-clicking to start the product, turn the product upside down (as shown in Figure 4). The default working time of the product is 40 seconds, and it shakes gently when working

products, the stirring effect is better;

5. After the juice is squeezed, the product will automatically enter the standby state, unscrew the machine head counterclockwise to drink, or insert a straw straight to drink; .

6. When the product cannot be started and the indicator light flashes red, insert the USB cable into the charging port (suitable for various 5V

Power supply); when charging, please tighten the machine head and the cup body, and then charge after the light flashes once, and the cutter head cannot be separated and exposed to charge. Knives and Cups When it is fully charged, the indicator light of the product is always on in white.

*This product can be charged with various smart phone chargers connected to the built-in USB charging cable, or it can be charged with a charging treasure

This product is charged, charged for 4.5 hours, can be freshly squeezed 10 cups, thank you for your use.

* This appliance is only suitable for charging with an input of 5.0V±2.0A and a maximum output energy of no more than 15W that meets the GB4706.1 certification.

orchestration.

Technical Parameters:

Product Model: JC-10

Charging current: 1.5A

Battery capacity: Quantity: 1500mAh

Battery voltage: 11.1V

Rated power: 120W

Product size: 156x104x255mm

Charging voltage: 5V


Stirring capacity: 800mL

Motor speed: 18000rpm


Schematic:

1. How to assemble and disassemble the handle

2. 800ML maximum stirring volume:
maximum scale for stirring juice



Packing:
push the handle up



Disassembly:
Push the handle down



Host.





Tons of barrels





Cup lid

Operation Method:



Cleaning Guidelines:



Symptoms:

Symptoms	Cause analysis	Method of exclusion
Unable to start or stopped during use, Machine with red light flashing	Not enough power	Please charge in time
Stop while in use There is a red light on for 5 seconds	Motor lock	Remove the food stuck on the blade. material, then reboot
Water leakage	Silicone ring assembly is not in place, Or the cup body is not tightened	Reinstall the silicone ring Tighten the host
Stop while in use There are red lights flashing 15 times	Continuous juicing multiple times leads, Tooover-temperature protection	Restart after 1 hour

For more information, please contact our
support team: support@porodo.net

www.porodo.net

Made in China

