



Portable Cordless
MINI VACUUM




Model: PB-50PVAC-WH

Please save and read this instruction manual carefully before use.


Product Introduction

- ① HEPA
- ② Dust collection bin
- ③ Power switch
- ④ Heat dissipation port
- ⑤ Handle
- ⑥ Power Port

Accessory



Charger



Multifunctional suction nozzle combination

Instructions for use




1.Connect the charger to fully charge the battery ; when charging: indicator light is red; When fully charged: indicator light turns green

Please charge with the switch disconnected

2.Connect corresponding accessories according to the usage situation (installation and use of accessories)


3.Turn on the power switch of the vacuum cleaner and start working

Please do not block the suction port and air outlet for a long time




Installation and use of accessories

1.Suction nozzle: suitable for dust cleaning of doors, seats, cabinet corners, drawers, Ashtray and other gaps



2.It is suitable for dust cleaning on various surfaces such as seat cushions, foot cushions, keyboards, and air conditioning vents




Disassembly Cleaning

1.Rotate the dust bin counterclockwise, remove the dust bin from the body

2.Remove the Haipa filter from the dust bin, put rubbish into rubbish bins

3.If necessary, you can use rag clean the dust cup, the filter screen can be cleaned with water. After washing, it must be thoroughly dried before reuse

4.To reinstall the dust bin, place the Haipa filter into the dust bin, Refer to step 1 to rotate and tighten in the opposite direction before use



Product Specification

Product Name	Voltage	Power	Product size	Weight	Dust cup capacity
RV-808	7.4V	50W	182x146x57MM	365g	0.12L

NOTE

- 1.Do not remove,repair or modify this product unless authorized repair personnel are involved
- 2.Do not cover the air inlet or exhaust outlet when operating this product, otherwise the product may deform and catch fire due to overheating.
- 3.Do not inhale combustibles, such as burning cigarette butts, when using this product.
- 4.Please place this product properly and keep it out of the reach of children.
- 5.Do not clean this product with severely corrosive liquids such as thinner, paint, etc.
- 6.If the vacuum cleaner does not have a dust collection bin and filter , is damaged or partially damaged, please do not use it and replace it in a timely manner, otherwise it may cause product damage.
- 7.Please ensure that the switch is turned off before charging, and it is strictly prohibited to use it while charging.