

porodo
LIFESTYLE



**VACUUM FRESH PORTABLE
JUICE & SMOOTHIE BLENDER**

MODEL:PD-P55JV-BK , PD-P55JV-WH, PD-P55JV-PL

Brief introduction:

Thank you for your patronage and welcome! In order to fully enjoy our services, please visit our official website. This juice cup can help you squeeze all the nutrients from the fruit into the cup, so that you can enjoy delicious and healthy juice every day. Innovative technology allows you to extract more healthy juice and clean products quickly in 1 minute. Fully integrated design, less space and better juicing effect.

Please read the instructions carefully:

Note: In order to avoid misuse, please read the instructions.

This product is a DC motor driven by lithium battery. The charger is universal for all kinds of smartphone USB chargers. Please first use the USB power cord provided by our company to fully charge the product before use. The charging time is less than 2 times and above is appropriate. In addition, please wash and dry all parts that come into contact with food before use.

Open the lid only after the product is closed and the stirring knife has stopped completely.

When cleaning this product, please make sure that the switch power is off and the silicone of the charging port is plugged tightly before cleaning the cup and host. Do not wash the main engine in water to prevent water from entering the main engine and damaging the electronic components.

Please do not juice this product for more than 5 times in order to avoid excessive load of electronic components causing heat and affecting product life.

This product is equipped with overload protection function. If the size of the food material is too large, the product will stop for protection and accompanied by red light for 5 seconds. After removing the material, it can be restarted. Each part of this product shall not be disinfected with hot water exceeding 60°C or microwave oven to avoid heat deformation and damage.

Do not put the main parts of the product into the dishwasher or cleaning equipment. Water cannot invade the main parts. Do not use steel velvet, abrasive cleaners, or corrosive liquids to clean the product.

This product is a special fresh juice machine, not mincing meat, grinding nuts, or soy products.

Do not invert the product or start the product when the straw is still inserted into the host or the silicone plug is not tightly plugged.

If unattended, always disconnect the juice machine before assembling, disassembling, or cleaning. Do not allow children to use the juicer without supervision.

Care should be taken when removing the mixing knife, cleaning the host, and mixing cup.

Turn off the power switch and disconnect the power supply before replacing accessories or touching moving parts.

Before discarding the appliance, the battery must be removed from the appliance using tools to pry.

15. Before discarding the appliance, remove the battery from the appliance and put the batteries in a separate battery waste bin. Dispose of them through a special person.

The appliance must be powered off when the battery is removed. Batteries should be disposed of safely.

This product is for household use only. If the product is improperly used, used for professional or semi-professional purposes, or the instructions in the manual are not followed, the warranty of this product will be void, and any resulting damage will not be covered by the company. The company disclaims any responsibility for such loss.

Before using the product for the first time, fully charge it and thoroughly clean the parts that come into contact with food.

The product is equipped with double safety protection measures. Only after the cup body is rotated to the fixed position of the fuselage, it is in the waiting operation state.

This appliance can only be charged if the input is 1.0=5.0A, and the maximum output energy is not more than 15W using a certified adapter.

Instructions for use:

Review the previous notes.

Wash the fruit and cut it into small pieces, approximately 1.5*1.5cm (Note: for fruits with stones, hard materials, thick skin, or hard shells, please remove them first).

Put the fruit into the cup, filling it up to approximately %60 of the maximum scale of the cup body. Then, fill the cup with water up to the maximum scale of the cup body. Afterward, turn the main engine to the cup. The indicator light will flash to indicate that the main engine is in place.

Note: Keep the fruit and water within the limit of the maximum scale to avoid spillage.

To enhance the taste, start the vacuumizing process first. Place the product upright on the tabletop and complete the vacuumizing after 40 seconds.

Note: Do not start vacuuming immediately after stirring to avoid damage caused by juice suction by the vacuum pump.

Double-click to start the product and reverse it (as shown in Figure 4). The default working time of the product is 40 seconds. During the working time, gently shake the product for better stirring effect.

After the juice is finished, the product will automatically enter the standby state. Press the exhaust button to open the top cover and you can drink it or plug it in.

If the product cannot be started and the indicator is blinking red while drinking through a straw, insert the USB cable into the charging port (applicable to each 5V power supply). When fully charged, the product indicator light will turn on in white.

red, insert the USB cable into the charging port (applicable to each

A 5V power supply): When fully charged, the product indicator light is on in white.

* This product can be charged by connecting various smart phone chargers with their own USB charging cable, and can also be power bank charge the product (note: when charging, it is necessary to tighten the mixing cup with the host machine before charging). It takes about 3 hours for it to be fully charged, and it can make about 8 cups of fresh juice. Thank you for your use.

Structural diagram:

Technical parameters:

Product model:JC-12

Battery voltage:7.4V—

Charging voltage:5V—

Charging current:1A

Motor speed:18000rpm

Mixing capacity:380ml

Net weight:553g

Product size: 210*86*94mm

①- Exhaust valve.

②- Upper cover

③- main engine


④- Handle rope

⑤- main engine sealing ring


⑥- Mixing knife

⑦- Mixing cup



⑧- Cup sets



Operation method.



Cleaning instructions:



Troubleshooting:

Symptoms	Cause analysis	Elimination method
Cannot stir or stop in use with a red light flashing	Low power	Please charge in time
When in use, the machine stops and the red light is on for 5 seconds.	Motor lock	Remove any food stuck in the blade and restart
Can not be vacuumed or stop in use with blue light flashing	Product tilt more than 30 degrees	Erect a product
Water leakage/ gas leakage	The silicone ring assembly is not in place or the cup body is not tightened	Reinstall the silicone ring and tighten the main engine.

Warranty card:

Dear customer, thank you for your patronage!

1. The shelf life of this product is one to one year from the date of purchase
2. Please present this warranty card and valid purchase certificate or official invoice when repairing.
3. If used improperly, disassembled without permission or caused by force majeure factors, please indicate the situation,

Customer name		Contact number	
Customer Address			
Date of Purchase		Place of purchase	
Shop seal			