

**PORODO**



**Porodo**

**50000mAh Power Bank  
Integrated Cables**

SKU: PD-PBFCH061

# Table of Contents


Specifications	2
Dimensions	2
Button Function	3
Charging the Power Bank	3
Charging Other Devices	3
Safety Warnings	3
Disposal	4
Warranty	5
Contact Us	5

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

## Specifications

Battery	50000mAh, 185Wh, 3.7V
USB-C Input	5V/2.6A, 9V/2A, 12V/1.5A, 18W Max
USB-C Output	5V/3A, 9V/2.22A, 12V/1.67A, 20W
USB-A Output	5V/3A, 9V/2A, 12V/1.5A, 5V/4.5A, 22.5W
	<b>Built-In Cable Output</b>
USB-C Output	5V/3A, 9V/2A, 12V/1.5A, 5V/4.5A, 22.5W
Lightning Output	5V/2.4A
Multi-Port Output	5V/3A (Max)
Size	66.3×69×147.5mm
Operating Temperature	-10°C to 60°C

## Dimensions



## Button Function

1. A short press of the button displays the power level on the digital tube.
2. Double-click the button to turn off the output.

## Charging the Power Bank

1. The power bank is charged via a Type-C input. A USB A to C cable is included in the package.
2. Connect the USB cable to the power source, then plug it into your power bank to start charging. The digital battery indicator will show the charging progress, indicating 100 % when fully charged.
3. Please unplug the power bank once it is fully charged.

## Charging Other Devices

To charge your mobile device, connect the power bank using one of the USB outputs and the built-in USB cables. Depending on the brand/device, a different cable than what is provided may be required.

**Note:** that charging speed will decrease when two devices are charged simultaneously.

## Safety Warnings

1. The product should be placed on a desktop during use.
2. The working temperature range for this product is 0°C to 35°C. Usage in environments hotter than 35°C or colder than 0°C is not recommended.
3. Do not expose the product to fire or water. Avoid cleaning it with a damp cloth to prevent leakage, short circuits, and other malfunctions.
4. Ensure the product is not covered with paper or other materials that could obstruct heat dissipation and cooling.
5. Avoid using this product unattended.
6. Do not disassemble this product. It contains no user-serviceable parts.
7. Avoid dropping, shaking, knocking, impacting, or squeezing the product.

- 8.** Never short-circuit the anode and cathode of the product to prevent fires.
- 9.** Keep the product out of reach of children.
- 10.** Always check that the output voltage of the charger matches this product before use to avoid overload, which can lead to smoke, fire, and other hazards.
- 11.** Please disconnect the charger once the device is fully charged.
- 12.** If you encounter any abnormal occurrences such as unusual odors, excessive heating, changes in color, deformation, or leakage during the operation of the mobile power supply, stop using immediately.
- 13.** Only use a certified branded adapter that is compatible with the power bank and meets all required standards.
- 14.** The replacement of batteries must be carried out by professional service agents and should be handled with care as improper handling can lead to an explosion risk.
- 15.** Only batteries of the same or an equivalent type should be used and replaced exclusively by qualified maintenance staff, not by untrained individuals.
- 16.** Batteries should never be exposed to environments that can cause overheating, such as direct sunlight or fire.
- 17.** Do not immerse in or expose the power bank to water.
- 18.** Avoid using the device if it has been submerged in water.
- 19.** Keep away from children, infants, and pets.
- 20.** Ensure that the appliance has adequate ventilation during use to prevent overheating and ensure safe operation.
- 21.** If the power bank starts to get warm, immediately unplug it from the power source or your mobile device and allow it to cool down.

## **Disposal**

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**