PORODO GAMING

PROFESSIONAL
RGB CONDENSER MICROPHONE

PDX519-BK

USER MANUAL

WHAT'S IN THE BOX?

1 X Microphone with Shock Mount
1 X Tripod Stand
1 X 2m USB cable
1 X User manual

PRODUCT DESCRIPTION



1. Mute Button - Tap to mute or unmute the mic. The RGB light will be off when the mic is muted and will be on when the mic is active.

2. Mic Capsule - Condenser microphone element with cardioid polar pattern.

3. USB C Port - Connect directly to your computer via the included USB cable.

4. Shock Mount - Isolate the mic and suppress the sound of unintentional rumbles and bumps.

5. Tripod Stand

6. USB C to USB A Cable (6.6') - For connecting the mic to the computer. (Only the included USB cable is 100% guaranteed for compatibility)

GUIDANCE FOR USE

1. Attach the mic onto the tripod with the thumbscrew.



2. Adjust the angle of the mic stand and tighten it.



3 . Tightly plug the included USB cable into the mic, and plug the USB- A connector into the USB port on your computer.



4. To get the optimum result, we suggest to speak into the mic within 7 inch.

MUTE BUTTON OPERATION

Tap the bottom of the microphone to mute/unmute the mic. The mic RGB light will indicate the current mute status of the mic.

Tips: The color of RGB light will change automatically in a preset mode. This model not be changed by any button on the mic or any app on the computer.



COMPUTER SETUP

APPLE MAC OS

1. Input Settings

1)Plug the free end of the provided USB cable into the USB port on your computer. The RGB light will be on, indicating the mic is powered. Your computer will automatically recognize the USB device and install a driver. There may be no pop- up window or message shown.



2) Next, click Sound to display the Sound preference pane.

3) Select FIFINE Microphone as Input Device. The mic input level is only controlled by the gain knob on the mic, and cannot be controlled directly on Mac or any software. When you speak into the mic, the input level meter will move, means the mic is picking up your voice.

2. Output Settings

Choose the output device you need and adjust the output volume here.

Tips:

• If you want to monitor your voice when using Macbook, you must turn on any recording software first(Audacity for example), make sure to click "Software Playthrough(Fon)", then click the record button to begin, otherwise you can not hear any sound when you speak to the mic.
• Choose the default Dictation&Spe ech software when you use the speech to text in Macbook, click "On" under Dictation window, so that your microphone can be recognized by the software.

• If your Mac only has USB-C port, you will need a genuine Apple USB-C to USB female adapter for connection. And please plug the USB adapter into your Mac first, then connect the mic with the adapter.



(Not included)

WINDOWS

1. Input Settings

Plug the USB cable into your computer and the RGB lighting will be on, indicating the mic is power red. Please wait for a few seconds when first time operation, since driver of microphone takes time to automatically install. There may be no pop-up window or message though. (If plu gging USB plug in a different USB port, driver installs again).
After installation, you can test the mic by speaking to it. If the mic picks up no sound, please follow procedures below.

1. Right-click the speaker icon at the bottom right of the screen. Click "Sounds".

2) Click the Sound control panel.

3) Select the Recording tab, and choose "FIFINE Microphone" as the default device. When you speak to mic, bar-type icon will turn green and bounce. If it remains unchanged please reset computer and replug the mic in another USB port. If there's still no "FIFINE Microphone", please contact Fifine after sales service.



4) The mic input level is only control led by the gain knob on the mic, and cannot be controlled directly on computer or any software.

2. Output Settings

1) Confirm the loudspeaker is open

2) Click the loudspeaker is being used-"Properties"–"levels", drag progress bar to adjust volume of output

3) If you want to monitor your recording, click Microphone "FIFINE Microphone" - "Properties" – "Listen" - click"Listen to this device" - "Apply". No sound is heard through earphones/ built-in speaker of computer if you don't follow this procedure. Tips. Click off "Listen to this device" when you are using any recording software or chatting software(Skype).



Tips for(Mac & Windows)

1. If computer prompts that it's unable to identify USB devices, please restart computer and replug the microphone into rear back USB port of your computer.
2. If the mic is recognized but no sound coming out, please check whether System Sound is muted and make sure the RGB lighting is on(means the mic is active).
3. If the mic is recognized but no sound comes out, and your PC is running on Windows 10, please go to settings > privacy > microphone and click the "Allow apps to access the microphone"is ON, then restart your PC.

4. If the sound of your mic is inconsistent or the volume randomly changes, please disable the sound activated recording function of the application (like "Automatically adjust volume" of Zoom). And if you're using Windows computer, please go to Settings-Privacy- Microphone, disable XBOX Console Companion and XBOX Game Bar under it.

RECORDING SOFTWARE SETTINGS

1. Make sure you have the correct input / output selected. Tips: log out the [Audacity] or other recording software you are using,if you find the USB microphone is unavailable. And restart the software after the mic is re-plugged.



Input: FIFINE Microphone

Output: Please choose your output device as needed

2. Make sure click off "listen to this device" in your computer system when you are using any recording software, or else you would hear duet of yourself just like too much echo.



3. There are several ways to improve the usage. Come to our website to search the Technical Support solution for your interested subject.

4. For windows computers, we recommend Audacity, and for Apple computers, you can use Apple's own QuickTime player to test the recording.

IMPORTANT NOTICE

• Setting your software levels
Correct adjustment of microphone level is important for optimum performance. Ideally, the microphone level should be as high as possible without overloading the input of your computer. If you hear distortion, or if your recording program shows levels that are consistently overloaded(at peak levels), turn the microphone volume (or level) down through the gain control on the mic. If your recording program shows insufficient level, you can increase the microphone gain through the gain control on the mic.

• Selecting software Many recording software can be chosen. Audacity, available for free online is a widely used software. If you plug in the mic AFTER you load Audacity, it may not recognize the mic while it may still record, the results will be unsatisfactory. If that happens, restart Audacity AFTER plugging the USB into your computer and click on Fifine Microphone option.

• Positioning the side-address mic To achieve the best frequency response, it is important to have the mic capsule (the side with pop filter)pointed at the user's mouth, instrument or any other sound source. For speaking/singing applications, the ideal position of the microphone is directly in front of the person who is speaking/ singing. The same position is optimal when miking an instrument such as an acoustic guitar, drums or piano. Test the mic in different distances to find the best sound for your particular setup.

• Protecting your microphone Avoid leaving your microphone in the open air or in areas where temperatures exceed 110° F (43° C) for extended periods. Extremely high humidity should also be avoided.

SPECIFICATIONS

Capsule Diameter: 16 mm
Polar Pattern: Uni-directional
Power Supply: 5+/-0.25V
Operating Current: 30-100mA
Sensitivity: -40+/-3dB

For more information, please contact our support team:
support@porodo.net

www.porodo.net /porodo /myporodo

Made in China

ملاحظة هامة

• تحديد مستويات برامج الإدخال الخاصة بك
بعد الضبط الصحيح لمستوى، الميكروفون أمرًا مهمًا لتحقيق الأداء الأمثل من الناحية المثالية، يجب أن يكون مستوى الميكروفون مرتفعًا قدر الإمكان دون زيادة التحميل على مدخلات جهاز الكمبيوتر الخاص بك.

• اختيار البرامج يمكن اختيار العديد من برامج التسجيل، برنامج Audacity ، المتاح مجانًا عبر الإنترنت، هو برنامج مستخدم على نطاق واسع. إذا قمت بتوصيل الميكروفون بعد تحميل Audacity، فقد لا يتعرف على الميكروفون بينما قد يستمر في التسجيل ، وستكون النتائج غير مرضية. إذا حدث ذلك، فأعد تشغيل Audacity بعد توصيل USB بجهاز الكمبيوتر الخاص بك وانقر على خيار Fifine Microphone.

• برامج الميكروفون المتوفر الخاص لتحقيق أقصى استخدام لديك - من الممكن أن تكون تسجيلة الميكروفون الخاص بك متوفرة على حاسوبك، على سبيل المثال، في حال استخدام أو الحوار أو أي مصدر صوت آخر. للمهمات المحددة ، فعلى سبيل المثال، تسجيلك الميكروفون أمام الشخص الذي يتحدث / يغني، سيكون الوضع نفسه صحيحًا بالنسبة لأي شخص أو الاستوديو الذي يستخدم الميكروفون، في مساعات مختلفة تعتمد على أفضل صوت لا يحادث الخاص.

• حماية الميكروفون الخاص بك تجنب ترك الميكروفون في الهواء الطلق أو في المناطق التي تتجاوز فيها درجات الحرارة ١١٠ درجة فهرنهايت (٤٣ درجة مئوية) لفترات طويلة. يجب أيضًا تجنب الرطوبة العالية جدًا.

مواصفات

قطر الكبسولة: ١٦ مم
النمط الاتجاهي: أحادي الاتجاه
مزود الطاقة: ٥ +/- ٠.٢٥ فولت
التشغيل الحالي: ٣٠-١٠٠مللي
الحساسية: -٤٠+/- ٣dB

لمزيد من المعلومات، يرجى الاتصال بفريق الدعم لدينا:
support@porodo.net

www.porodo.net /porodo /myporodo

Made in China

---

١. إذا كان صوت الميكروفون الخاص بك غير متناسق أو تقوم مستوى الصوت بشكل عشوائي ، فيرجى تعطيل وظيفة تسجيل الصوت المنشط للتطبيق مثل "ضبط مستوى الصوت تلقائيًا" تكبير/ تصغير. وإذا كنت تستخدم جهاز كمبيوتر يعمل بنظام Windows ، فانتقل إلى الإعدادات - الخصوصية - الميكروفون ، وقم بتعطيل تطبيق XBOX Game Bar و XBOX Console Companion الموجود أسفله.

تسجيل إعدادات البرنامج

١. تأكد من تحديد الإدخال / الإخراج الصحيح. قم بتسجيل الخروج من [Audacity] أو أي برنامج تسجيل آخر تستخدمه إذا وجدت أن ميكروفون USB غير متاح. وأعد تشغيل البرنامج بعد إعادة توصيل الميكروفون.



Input: FIFINE Microphone

Output: Please choose your output device as needed



٢. تأكد من قيام "الاستماع إلى هذا الجهاز" في علامة التبويب التشغيل الخاص بك في نظام الكمبيوتر الخاص بك. عند استخدام أي برنامج تسجيل ، وإلا فسوف تسمع صوت تأتي خلف ثانية من الخلف.

٣. هناك عدة طرق لتحسين الاستخدام. تعال إلى موقعنا على الإنترنت للبحث في الدعم الفني عن موضوعك المهتم.

٤. بالنسبة لأجهزة الكمبيوتر التي تعمل بنظام Windows ، نوصي باستخدام Audacity. وبالنسبة لأجهزة كمبيوتر Apple ، يمكنك استخدام مشغل QuickTime الخاص بشركة Apple لاختبار التسجيل.

٢. إعدادات الإخراج

قم باختيار جهاز الإخراج الذي تريده واضبط حجم الإخراج هنا.

للتعليمات (لأجهزة Mac & Windows)

١. إذا كان جهاز الكمبيوتر يطلب منك أنه غير قادر على التعرف على أجهزة USB ، فيرجى إعادة تشغيل الكمبيوتر و أعد توصيل الميكروفون بمنفذ USB الخلفي الخلفي. لجهاز الكمبيوتر الخاص بك.
٢. إذا تم التعرف على الميكروفون ولكن لا تخرج صوت ، فتحقق من أن خيار "تشغيل هذا الجهاز" محدد في علامة تبويب الصوت الخاص بنظام الكمبيوتر الخاص بك. إذا كنت تستخدم أي برنامج تسجيل ، فتأكد من أن الميكروفون نشط.
٣. إذا تم التعرف على الميكروفون ولكن لا تخرج صوت ، فتحقق من أن مستوى الإدخال في نظام الكمبيوتر الخاص بك ليس منخفضًا جدًا. إذا كان الأمر كذلك ، فقم بزيادة مستوى الإدخال. يمكنك أيضًا التحقق من مستوى الإدخال في برنامج التسجيل الخاص بك.
٤. بالنسبة لأجهزة الكمبيوتر التي تعمل بنظام Windows ، نوصي باستخدام Audacity. وبالنسبة لأجهزة كمبيوتر Apple ، يمكنك استخدام مشغل QuickTime الخاص بشركة Apple لاختبار التسجيل.



١. اختر فتح لوحة الأصوات في لوحة التحكم.



٢. انقر بزر الماوس الأيمن فوق رمز الصوت الخاص بك في شريط المهام. حدد "أصوات".



٣. حدد علامة التبويب تسجيل. وانقر فوق "الميكروفون" (جهاز الميكروفون) عندما تتحدث إلى الميكروفون ، سيتحرك رمز نوع الشريط إلى اليمين والخضرة و يرتد. إذا بقي دون تغيير ، فيرجى إعادة تعيين الكمبيوتر وإعادة توصيل الميكروفون في منفذ USB آخر. إذا لم يكن "ميكروفون FIFINE" ، فيرجى الاتصال بخدمة ما بعد البيع Fifine.

٤. انتقل إلى علامة التبويب الإدخال وحدد "ميكروفون FIFINE" (جهاز الميكروفون) عندما تتحدث إلى الميكروفون ، يجب أن يتحرك شريط الإدخال الأخضر بشكل متناسب مع مستوى صوتك. إذا لم يتحرك ، فتحقق من أن الميكروفون الخاص بك غير مكتوم وأن مستوى الإدخال ليس منخفضًا جدًا.

٢. إعدادات الإخراج

١) قم بتوصيل كابل USB المرفق بمنفذ USB المتوفر في جهاز الكمبيوتر الخاص بك. سيضيء ضوء RGB ، مما يشير إلى تشغيل الميكروفون. سيقوم نظام الكمبيوتر الخاص بك تلقائيًا بالتعرف على الجهاز وتثبيت برنامج التشغيل. قد لا تكون هناك نافذة منبثقة أو رسالة على الإطلاق.

٢) انقر فوق أيقونة الصوت في الزاوية السفلية اليمنى من سطح المكتب. حدد "الأصوات".

٣) حدد علامة التبويب "تسجيل" ، وحدد "ميكروفون FIFINE" كجهاز الإدخال الافتراضي. عندما تتحدث إلى الميكروفون ، يجب أن يتحرك شريط الإدخال الأخضر بشكل متناسب مع مستوى صوتك. إذا لم يتحرك ، فتحقق من أن الميكروفون الخاص بك غير مكتوم وأن مستوى الإدخال ليس منخفضًا جدًا.

٤) يتم التحكم في مستوى إدخال الميكروفون فقط بواسطة مقبض الكسب في الميكروفون ، ولا يمكن التحكم فيها مباشرة على الكمبيوتر أو أي برنامج.

٢. إعدادات الإخراج

قم باختيار جهاز الإخراج الذي تريده واضبط حجم الإخراج هنا.

للتعليمات (لأجهزة Mac & Windows)

١. إذا كان جهاز الكمبيوتر يطلب منك أنه غير قادر على التعرف على أجهزة USB ، فيرجى إعادة تشغيل الكمبيوتر و أعد توصيل الميكروفون بمنفذ USB الخلفي الخلفي. لجهاز الكمبيوتر الخاص بك.
٢. إذا تم التعرف على الميكروفون ولكن لا تخرج صوت ، فتحقق من أن مستوى الإدخال في نظام الكمبيوتر الخاص بك ليس منخفضًا جدًا. إذا كان الأمر كذلك ، فقم بزيادة مستوى الإدخال. يمكنك أيضًا التحقق من مستوى الإدخال في برنامج التسجيل الخاص بك.
٣. إذا تم التعرف على الميكروفون ولكن لا تخرج صوت ، فتحقق من أن الميكروفون نشط.
٤. بالنسبة لأجهزة الكمبيوتر التي تعمل بنظام Windows ، نوصي باستخدام Audacity. وبالنسبة لأجهزة كمبيوتر Apple ، يمكنك استخدام مشغل QuickTime الخاص بشركة Apple لاختبار التسجيل.

تشغيل زر كتم الصوت

اضغط على الجزء السفلي من الميكروفون لكتم / إلغاء كتم صوت الميكروفون. سيتغير ضوء الميكروفون RGB إلى حالة كتم الصوت الحالية للميكروفون.

تلميحات: سيتغير لون ضوء RGB تلقائيًا في وضع محدد مسبقًا. هذا الوضع لا أكون تم تعيينه بأي زر على الميكروفون أو أي تطبيق على الكمبيوتر.

إعداد الحاسوب

APPLE MAC OS

١. إعدادات الإدخال

١) قم بتوصيل كابل USB المرفق بمنفذ USB المتوفر في جهاز الكمبيوتر الخاص بك. سيضيء ضوء RGB ، مما يشير إلى تشغيل الميكروفون. سيقوم نظام الكمبيوتر الخاص بك تلقائيًا بالتعرف على الجهاز وتثبيت برنامج التشغيل. قد لا تكون هناك نافذة منبثقة أو رسالة على الإطلاق.

٢) انقر فوق أيقونة الصوت في الزاوية السفلية اليمنى من سطح المكتب. حدد "الأصوات".

٣) حدد علامة التبويب "تسجيل" ، وحدد "ميكروفون FIFINE" كجهاز الإدخال الافتراضي. عندما تتحدث إلى الميكروفون ، يجب أن يتحرك شريط الإدخال الأخضر بشكل متناسب مع مستوى صوتك. إذا لم يتحرك ، فتحقق من أن الميكروفون الخاص بك غير مكتوم وأن مستوى الإدخال ليس منخفضًا جدًا.

٤) يتم التحكم في مستوى إدخال الميكروفون فقط بواسطة مقبض الكسب في الميكروفون ، ولا يمكن التحكم فيها مباشرة على الكمبيوتر أو أي برنامج.

إعدادات للاستخدام

1) Confirm the loudspeaker is open

2) Click the loudspeaker is being used-"Properties"–"levels", drag progress bar to adjust volume of output

3) If you want to monitor your recording, click Microphone "FIFINE Microphone" - "Properties" – "Listen" - click"Listen to this device" - "Apply". No sound is heard through earphones/ built-in speaker of computer if you don't follow this procedure. Tips. Click off "Listen to this device" when you are using any recording software or chatting software(Skype).

Tips for(Mac & Windows)

1. If computer prompts that it's unable to identify USB devices, please restart computer and replug the microphone into rear back USB port of your computer.
2. If the mic is recognized but no sound coming out, please check whether System Sound is muted and make sure the RGB lighting is on(means the mic is active).
3. If the mic is recognized but no sound comes out, and your PC is running on Windows 10, please go to settings > privacy > microphone and click the "Allow apps to access the microphone"is ON, then restart your PC.

4. If the sound of your mic is inconsistent or the volume randomly changes, please disable the sound activated recording function of the application (like "Automatically adjust volume" of Zoom). And if you're using Windows computer, please go to Settings-Privacy- Microphone, disable XBOX Console Companion and XBOX Game Bar under it.

RECORDING SOFTWARE SETTINGS

1. Make sure you have the correct input / output selected. Tips: log out the [Audacity] or other recording software you are using,if you find the USB microphone is unavailable. And restart the software after the mic is re-plugged.

Input: FIFINE Microphone

Output: Please choose your output device as needed

2. Make sure click off "listen to this device" in your computer system when you are using any recording software, or else you would hear duet of yourself just like too much echo.

3. There are several ways to improve the usage. Come to our website to search the Technical Support solution for your interested subject.

4. For windows computers, we recommend Audacity, and for Apple computers, you can use Apple's own QuickTime player to test the recording.

ملا ف العندوق:

١ X ميكروفون مع حامل للصحات
١ X حامل ثلاثي القوائم
١ X كابل يو اس ب ٢ م / ٦ أقدام
١ X دليل المستخدم

وصف المنتج

١. زر الصوت - قم بلمس زر الصوت الميكروفون أو إلغاء كتم صوت الميكروفون. سيتم تشغيله عندما يكون الميكروفون نشطًا.
٢. كبسولة الميكروفون - مكثف بنمط قطبي فائق الشكل.
٣. منفذ يو اس ب من نوع - قم بتوصيله مباشرة بجهاز الكمبيوتر الخاص بك عبر كابل يو اس ب المرفق.
٤. حامل الصدمة
٥ حامل ثلاثي القوائم
٦. كابل الميكروفون وقمع من الحدمدة والمدحات غير المقصودة

٥. حامل ثلاثي القوائم

٦. توصيل كابل يو اس ب إلى الكمبيوتر وتوصيل الميكروفون بالكمبيوتر المضيف يو اس ب المضمنة المحلل مضمون ١٠ لتوافق.

PORODO GAMING

ميكروفون مكثف احترافي ار جي بي

PDX519-BK

دليل الاستخدام