

PORODO
LIFESTYLE



Porodo Lifestyle

Turbo Jet Air Blower

SKU: PD-LFST129




Table of Contents

Specifications	2
Schematic View	3
Package Contents	4
Usage Guide	4
Charging	4
Safety Instructions	4
Disposal	5
Warranty	5
Contact Us	5

Specifications

Material	ABS, PC, Metal
Battery	2500mAh
Input Voltage	5V/2A
Charging Time	2H
Charging Interface	Type-C
Working Time	Up to 2.5H
Motor Speed	20000RPM, 30000RPM, 40000RPM, 130000RPM
Speed Levels	4
Airflow Capacity	160g
Airflow Speed	35m/s
Product Size	32 x 50 x 127mm
Product Weight	198g
Model Number	LFS129

Schematic View



Magnetic Air Nozzle



Desk Base

Package Contents

Turbo Fan
Charging Cable
Magnetic Air Nozzle
Desk Base

Usage Guide

1. Powering On and Turbo Mode:

- 1.1 Long press the Power/Fan mode button to turn on the device.
- 1.2 Press and hold the Turbo button to operate at maximum power.
- 1.3 Release the Turbo button to stop.

2. Adjusting Fan Speed:

- 2.1 Short press to cycle through speeds from 1 to 3.
- 2.2 Long press again to turn off the fan.

Charging

- 1. Connect the fan using the charging cable provided in the package.
- 2. Begin charging. The battery indicator (red) will illuminate.
- 3. Charging is complete when the battery indicator light turns off.

Safety Instructions

- 1. This fan is not waterproof. Do not submerge it in water.
- 2. This fan is not a toy. Close supervision is necessary when it is used near children. Keep it out of reach of children.
- 3. Do not cover the nozzle, air outlet, or inlet while the device is in use, as this may cause damage.
- 4. Do not use this fan in environments where the temperature exceeds 60°C (140°F).
- 5. Regularly remove and clean the attachments on the nozzle, air outlet, and inlet.

6. Do not modify or attempt to repair this fan by yourself.
7. Do not insert your fingers or allow hair to be sucked into the air inlet. Also, avoid pointing the air outlet towards anyone's eyes, nose, or ears.
8. Due to the high RPM and working current, avoid using the fan continuously for long periods. Try not to use it continuously for more than one minute.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**