



2-IN-1 FOLDABLE OUTDOOR FLASHLIGHT

PD-LS5WFLS

SAFETY INSTRUCTIONS

- To operate this device safely, the user must have read and understood these instructions for use before using the device for the first time.
- Retain all instructions for use, and safety instructions for future reference.
- If you sell or pass the device on, you must also hand over these operating instructions.
- The device must only be used when it functions properly. If the product or part of the product is defective, it must be taken out of operation and disposed of correctly.
- Never use the device in a room where there is a danger of explosion or in the vicinity of flammable liquids or gases.
- This product is sensitive to electrostatic discharge. During the electrostatic discharge, the lamp may switch on and off automatically.

HANDLING RECHARGEABLE DEVICES

- **Danger of fire!** Only use batteries approved by the manufacturer. Only use chargers approved by the manufacturer. Keep battery away from metal objects that could cause short circuiting when not in use. There is a risk of injuries and fires.
 - Prior to connecting the charger, verify that the power supply connection corresponds with the connecting data of the device.
 - The fuse must be a residual current circuit-breaker with a measured residual current of no more than 30 mA.
 - Only charge the battery in closed rooms.
 - Fluid can escape from the battery when used incorrectly. Battery fluid may result in skin irritations and burns. Avoid contact! In the event of accidental contact, rinse thoroughly with water.
- Immediately seek the aid of a physician in the event of eye contact.

CHARGING

Note: Important! Charge the work light immediately after purchase, after each use, and at least every 6 months. Failure to do this will reduce the battery's capacity and may void the warranty.

- Connect the micro USB end of the charging cable to the micro USB port on the side of the work light. Insert the USB end of the cable into the USB port on the wall charger.

OPERATING INSTRUCTIONS

- Hang the work light, using the hook on the back.
- The magnets may be used instead. Attach to any ferrous metal surface.
- Direct the lens away from your eyes before turning on the work light.
- Starting situation: Work light is off
- Push the [ON/OFF] button 1x: Main light LED with 100% brightness
- Push the [ON/OFF] button 2x: Lateral COB LED with 50% brightness
- Push the [ON/OFF] button 3x: Lateral COB LED with 100% brightness
- Push the [ON/OFF] button 4x: Light is off
- Hold down [ON/OFF] button: Red light

MAINTENANCE INSTRUCTIONS

- After use and before performing maintenance, disconnect the work light from the charger.
- Use a dry cloth to wipe any dirt or oil from the charger, cord and case.
- Any servicing should be performed by qualified service personnel.

STORAGE INSTRUCTIONS

- Store inside, in a cool, dry place.
- Take care to avoid/prevent damage to the charger, cord and unit.
- Failure to do so could result in personal injury or property damage.
- Charge the work light's internal battery immediately after purchase, after every use and every 6 months.
- All batteries are affected by temperature. The ideal storage temperature is at 21°C. The internal battery will gradually self-discharge (lose power) over time, especially in warm environments. Leaving the battery in a discharged state may result in permanent battery damage. To ensure satisfactory performance and avoid permanent damage, charge the internal battery every 6 months.

TECHNICAL DATA

Light (main): 3 W SMD LED
Light source (lateral): 5 W COB LED
Protection class: III
Battery pack type: Li-Ion, 3,7 V,
1500 mAh

DISPOSAL

Disposal of the appliance

A crossed-out wheellie bin icon means: Batteries and rechargeable batteries, electrical or electronic devices must not be disposed of with household waste. They may contain substances that are harmful to the environment and human health. Consumers must dispose of waste electrical devices, spent portable batteries and rechargeable batteries separately from household waste at an official collection point to ensure that these items are processed correctly. Information on returning these items is available from the seller. Sellers are required to accept these items free of charge. Batteries, rechargeable batteries and lamps that are not permanently installed in waste electrical equipment and can be removed in a non-destructive way must be removed and disposed of separately before disposal of the equipment. Lithium batteries and rechargeable battery packs of all systems are only to be handed in to the waste collection points in a discharged state. The batteries must always be protected against short circuits by taping off the poles. All end users are responsible for deleting any personal data stored on waste devices prior to their disposal.

Disposal of the packaging

The packaging consists of cardboard and correspondingly marked plastics that can be recycled.

- Make these materials available for recycling.
- Do not burn accumulators. Risk of explosion!

For more information, please contact our support team:
support@porodo.net



Made in China

www.porodo.net /porodo /myporodo