

porodo
LIFESTYLE

UASER MANUAL




PORTABLE HANDHELD TURBO COOLING FAN

MODEL: PD-LSMPTF

Thank you for purchasing and using this product!

In order to bring you a better experience, please read this manual carefully before using this product and keep it properly for future reference. The company reserves the right to improve the product, packaging and manual, if there is any change without notice, please in kind prevail.

Overview



Instructions

1. Switch/Gear Adjustment: In the off state, short press the switch/gear button to turn on, and the default wind is 1st gear, short press again to 2nd gear wind; short press 3 times to 3rd gear wind; short press 4 times to shut down. And so on.
2. Using on Table/ Handheld Using: Insert the handle of the fan into the base and you can put it on the table to use. Take out the fan from the base and you can carry it in your hand to use.
3. Charging: Plug in the charging cable and connect to the adapter, then you can charge the fan. The indicator light is always red during charging and it goes out when the charging is completed.

Specifications

Product Name	Portable Handheld Fan
Material	ABS
Speed Level	Low/Medium/High
Input	5V=1A
Rated Power	5W
Battery Capacity	2000mAh
Charging Time	3.5H
Working Temperature	0°C-45°C

Packing List

1*Battery Fan, 1*Base, 1*Charging Cable, 1*Lanyard,
1*User Manual

Attentions

1. Do not tamper, disassemble, or attempt to repair this product without authorization.
2. Keep it away from the fire.
3. Don't put fingers into the fan. Children should use products under the supervision of adults.
4. Fan blades will be at high-speed rotation while working. Don't put anything into the air outlet/ air inlet, otherwise it may be seriously damaged.
5. Please avoid subjecting the product to shocks such as long-distance vibration of falling from height.
6. Please do not in a bath or places with high humidity, do not submerged in water. otherwise, it will cause a short-circuit.
7. The battery may be damaged if the product is left unused for a long time. It is recommended to charge it at least once every 3 months.
8. When not in use, please clean the oil and dust on the surface of the product, and store in a dry and ventilated place. Do not squeeze.
9. When the product is fully charged, the charging cable should be pulled out in time, overcharging will affect the service life of the product.
10. If any abnormality occurs during use or charging, please stop using immediately.

⚠ Warning

This product contains lithium battery, do not place in high temperature environment. Do not disassemble, impact, squeeze or put into fire. Do not continue to use if there is serious swelling. To reduce pollution and protect the earth's environment, please separate it from household waste and recycle it.