porodo

User Manual

PD-3094-BK

PD Power Bank 30000mAh

20W Power Delivery and Quick Charge 3.0

PRODUCT INTRODUCTION PARTS

1. Micro Input
2. lightning Input
3. USB1 Output
4. USB2 Output
5. Type-C Input&Output
6. Digital display



FEATURES

1. Press turn on/off button, to show you the remaining capacity
2. Multiple safety protection system to ensure devices safety: protection for overcharge, over-voltage, over-current and short circuit.
3. PD20W Max.,USB A 22.5W max.,quick charge for mobile devices.

SPECIFICATION

Micro USB In: 5-9V/2A, 12V/1.5A 18W
USB-C PD In & Out: 5V/3A, 9V/2.2A, 12V/1.67A 20W (Max)
USB Out: 5V/3A, 9V/2A, 12V/1.5A 18W
Total Output: 20W Max

FIT FOR

Tablet, iPhone, iPod, Mobile phone, PSP, NDS and so on.

HOW TO CHARGE THE MOBILE POWER BANK

1. Charge by Computer or Adapter: connect the mobile power with cable.
2. Digital number will flash while charging, lits up with white color all the time if full charge. Please charge and restert the mobile power bank while it is under lock status.



HOW TO USE THE POWER BANK TO CHARGE YOUR DEVICE

1. Use the standard cable to connect the power bank and device.
2. Will turn on automatically if connecting with your mobile devices.
3. Disconnect your device after full charging.

CAUTION

1. Before first use,charge mobile powerbank to maximum capacity.
2. Please make sure that a standardcable with the appropriate specification is used,or it may lead to mobile power bank damage.
3. Please confirm the voltage of electric device is 5V before charging it.
4. Do not drop,knock,disassemble or attempt to repair the mobile power by yourself.
5. Do not immerse or put the mobile power in water or damp place.
6. Do not expose or put the mobile power near to heat sources or flammable place.
7. Do not leave the mobile power bank in strong sunlight or high temperatures as this will lead to mobile power bank damage.
8. Keep the mobile power away from children.
9. Do not put any foreign object into the USB input or output ports as this may create a short circuit or damage the mobile power bank.
10. Please ensure a complete charge is completed every four months to ensure optimal function.