

PORODO *Blue*



Porodo Blue
Pop Tune True Wireless
Deep Base Earbuds

SKU: PBSTS190WH

Table of Contents

Specifications	2
Connection Guide	2
Instructions for Use	3
Charging and Power	4
Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Specifications

Model Number	PB-STS190
Input	5V/1A
Charging Case Capacity	180mAh
Earbuds Capacity	28mAh
Recharge Time	1.5H
Music Playtime	Up to 4H
Charging Interface	Type-C
Bluetooth	V5.4
Bluetooth Frequency	2.4GHZ-2.48GHZ
Bluetooth Range	>10m

Connection Guide

- 1.** For the first use, remove the earbuds from the charging case. The earbuds will automatically power on.
- 2.** Next, enable Bluetooth on your device and search for the product named 'PB-STS190' to connect.
- 3.** Once connected, the earbuds will automatically pair with your device each time they are removed from the case and need to reconnect every time.

Instructions for Use

Power On: Take the earphones out of the charging case to power them on.

Power Off: Long press the multi-function button for 5 seconds, or place the earphones back into the charging case to turn them off.

TWS Pairing: The earphones will automatically pair when the product is turned on for the first time.

TWS Usage: Both earphones can be used together, or you can use them individually.

Pause/Play: Press the multi-function button to pause or play music.

Previous Song: Press the left multi-function button twice to skip to the previous song.

Next Song: Press the right multi-function button twice to skip to the next song.

Volume Up: Press the right multi-function button three times to increase the volume.

Volume Down: Press the left multi-function button three times to decrease the volume.

Answer an Incoming Call: Press the multi-function button once to answer an incoming call.

Voice Assistant: Press and hold the multi-function button for 2 seconds to activate the voice assistant.

Reject a Call: Press and hold the multi-function button for 2 seconds to reject an incoming call.

Battery Display: The battery display is supported only on iOS devices and some Android system devices.

Charging and Power

Sleep Mode: When there is no active connection, the earphones will automatically power off after approximately 3 minutes of inactivity.

Automatic Connection: After the earphones are turned on again, Bluetooth will automatically reconnect to the paired phone.

Automatic Power-Off: The earphones will automatically power off when placed back into the charging case.

Charging Case Charging: The indicator light on the charging case will flash while charging. Once fully charged, the indicator light will remain on.

Earphone Charging: Place the earphones back into the charging case to begin charging.

Precautions

1. Handle this product with care. Avoid dropping or applying heavy pressure to prevent damage, and keep it away from high temperatures and humid environments.
2. Keep the product away from Wi-Fi routers and other high-frequency transmitting devices, as they can interfere with the signal reception, leading to

sound disruptions and disconnections.

3. Ensure the product is used within an effective range (within 10 meters) without physical obstructions (such as walls) between the Bluetooth device and the product for optimal performance.

4. To prevent charging failure due to battery hibernation, keep the charging case charged above 20% to ensure it is ready for use.

5. Do not expose the product to moisture or submerge it in water to prevent internal damage and functionality issues.

6. When not in use, store the product in a cool, dry place to maintain its longevity and performance.

7. Clean the product regularly with a soft cloth to remove dust or dirt, but avoid using harsh chemicals that could damage the surface.

8. Always charge the product with the recommended adapter to avoid damaging the battery or causing overheating.

Note: This product can be connected with any device that has Bluetooth functionality.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**