

PORODO



Porodo

**4800mAh SnapCharge
MagSafe Power Bank**

SKU: PDPBH22BK

Table of Contents

Product Overview	2
Specifications	2
Compatible Devices	3
Charging Instructions	3
Camera Shutter Setup	5
Package Contents	5
Safety Precautions	5
Disposal	6
Warranty	7
Contact Us	7

product Overview

The Porodo 4800mAh SnapCharge MagSafe Power Bank with Camera Shutter Remote features MagSafe compatibility, allowing it to magnetically attach to MagSafe-enabled phones for seamless wireless charging. With a built-in camera shutter remote, it offers added convenience for content creators, making it easier to capture selfies and group shots without needing to touch the phone. The power bank's compact design ensures easy portability, making it perfect for travel and daily use. With a reliable 4800mAh capacity, it keeps your device charged throughout the day, making it an ideal solution for everyday users, travelers, and anyone looking for a multifunctional accessory for their phone. Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Specifications

Battery Capacity	4800mAh
USB-C Input	5V/3A, 9V/2A Max
USB-C Output	5V/3A
Wireless Output	10W Max
Bluetooth Version	V5.1
Material	ABS

Product Weight	193g
Product Dimensions	40 x 91 x 121.5mm
Model Number	PDPBH22

Compatible Devices

- iPhone 12

iPhone 12 Pro

iPhone 12 Pro Max

iPhone 12 mini

iPhone 13

iPhone 13 Pro

iPhone 13 Pro Max

iPhone 13 mini

iPhone 14

iPhone 14 Plus
- iPhone 14 Pro

iPhone 14 Pro Max

iPhone 15

iPhone 15 Plus

iPhone 15 Pro

iPhone 15 Pro Max

iPhone 16

iPhone 16 Plus

iPhone 16 Pro

iPhone 16 Pro Max

Charging Instructions

1. Charging Compatibility:

The magnetic power bank can be charged using a 5V, 3A, 9V/2A MAX adapter. Four white LED indicators show the battery power at different levels:

- 25 %
- 50 %
- 75 %
- 100 %

When fully charged, all four lights will turn white, indicating the power bank is ready for use.

2. Wireless Charging with Automatic Voltage Adjustment:

Press the power button to activate the green indicator light (breathing mode). Once this is on, you can place your phone on the wireless charging area. The power bank will automatically adjust the voltage for optimal charging. If the green light flashes continuously, it means a foreign metal object has been detected in the charging area (such as a coin or key). Charging will stop automatically to prevent overheating or damage.

3. Low Power Consumption Mode:

If there is no device placed on the charging pad for 42 seconds, the power bank will enter a low power consumption mode to preserve energy.

4. Power On and Charging:

To power on the device, press the power button. Place your phone on the wireless charging area. If the white indicator shows sufficient power, you can connect the data cable to charge your phone. To stop the charging output, double-press the power button; the green indicator will turn off, signaling that no power is being supplied.

Note: The Type-C port on this magnetic power bank is designed to function as either an input or output port, but not simultaneously. When the Type-C port is connected, the power bank will automatically detect whether it's being used for input or output and adjust its functionality accordingly. The power bank is designed to work efficiently within an environmental temperature range of 0°C to 40°C. Please ensure the device operates within this range to maintain optimal performance.

Camera Shutter Setup

1. Bluetooth Pairing for Camera Shutter:

Press the camera button for 3 seconds until the blue light flashes. The power bank will automatically begin searching for a mobile phone to pair with via Bluetooth. Once paired successfully, the blue light will remain on, indicating that the camera shutter function is ready for use.

2. Turning Off Bluetooth Connection:

If you wish to disconnect the Bluetooth connection, press and hold the camera button for 3 seconds. The blue light will flash for 3 seconds and then turn off, signaling that the Bluetooth connection has been terminated.

Note: Type-C Port Usage: The Type-C port on this magnetic power bank is designed to function as either an input or output port, but not simultaneously. When the Type-C port is connected, the power bank will automatically detect whether it's being used for input or output and adjust its functionality accordingly. The power bank is designed to work efficiently within an environmental temperature range of 0°C to 40°C. Please ensure the device operates within this range to maintain optimal performance.

Package Contents

- Power Bank
- Type C Data Cable

Safety Precautions

1. Do not expose the power bank to direct sunlight.
2. Use only the recommended cables and adapters for charging the power

bank. Avoid using third-party accessories that may cause overheating or damage.

3. Always disconnect the device from your phone after charging to prevent unnecessary power consumption and overheating.

4. Do not use the power bank in wet or humid conditions. Avoid exposure to water to prevent internal damage or short-circuiting.

5. Store the power bank in a cool, dry place when not in use. Do not store it in areas with high temperatures, such as inside a car on a hot day.

6. If the power bank is not used for extended periods, charge it at least once every 3 months to maintain battery health.

7. Do not drop or subject the power bank to strong impacts, as this can damage the internal components or the camera shutter button.

8. Keep the power bank out of reach of young children to prevent accidental ingestion of small parts or misuse of the camera shutter function.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**