

PORODO
LIFESTYLE



Porodo Lifestyle


**5-In-1
Hair Styling Tool**

SKU: PDLFST218

Table of Contents

Product Diagram	2
Instructions for Use	2
Specifications	3
Safety Precautions	3
Disposal	4
Warranty	5
Contact Us	5

Product Diagram



Instructions for Use

This product works effectively on washed hair. After shampooing, use a hair dryer to blow dry your hair, ensuring it is smooth and tangle-free.

1. Insert the power plug into the socket to power on the device.
2. Press the standby/temperature adjustment button to start the device and switch to the temperature setting that suits your hair type. Preheat for 1 to 3 minutes before beginning use.
For fine and soft hair: 160°C.
For normal hair: 180°C.
For thick and dry hair: 200°C.
3. Press the standby/temperature gear adjustment button to start, and the default temperature setting will be 180°C upon startup.

4. After starting, press the standby/temperature gear switch button to adjust the temperature. The available temperature settings cycle through 160°C, 170°C, 180°C, 190°C, and 200°C in sequence.
5. After adjusting the temperature, the setting will be confirmed after 10 seconds. Three beeps will indicate the setting has been completed.
6. Long press the standby/temperature gear adjustment button to enter standby mode. The device will also automatically enter standby mode after 40 minutes of operation.

Specifications


Rated Voltage	110V-240V
Rated Frequency	50Hz
Rated Power	50W-120W
Curling Barrels	25mm & 32mm
Temperature Range	160°C - 200°C
Power Cord	UK 3-Pin Plug
Unit Weight	980g
Model Number	PDLFST218

Safety Precautions

Before using the product, carefully read the safety manual and keep it for future reference.

1. **Danger:** Do not use this device near bathtubs, showers, washbasins, or any containers that hold water. Water can pose a risk of electric shock.

2. Please keep the appliance out of children's reach, specially during use and cooling down after use.
 3. Use the device on a flat, dry surface to ensure stable operation. Avoid using it on wet or damp surfaces.
 4. Do NOT leave the appliance unattended when it is connected to the power supply.
 5. After using the device, always turn it off and unplug it. Never leave it plugged in when not in use.
 6. Do not use the device continuously for more than the recommended time. Give it time to cool down before using again.
 7. Check the device and supply cord for signs of damage and wear before each use. if the supply cord is damaged, it must be replaced by the manufacturer, or similarly qualified people in order to avoid danger.
 8. After use, allow the device to cool down completely before storing it in a safe, dry place. Do not store it in humid or wet environments.
- Caution:** This appliance should not be used by individuals with reduced physical, sensory, or mental abilities, or those without experience, unless under proper supervision or guidance.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**