

PORODO
LIFESTYLE



Porodo Lifestyle

**CLOTHING BUKHOUR
INCENSE BURNER**

SKU: PD-LFST115

Table of Contents

Product Overview	2
Product Features	2
Operation Guide	3
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Porodo Clothing Bukhour Incense Burner is a versatile and innovative product designed to enhance the ambiance of your home, office, or boutique. Standing at 186 cm, it features a sturdy and stable tripod base with a non-skid design to ensure it remains steady, even during use. The smart hanger hook design allows for easy placement of clothes, while the incense ventilation holes help diffuse pleasant aromas. Ideal for wrinkle removal and scenting, the Bukhour burner uses your favorite incense to refresh clothes effortlessly. This product is perfect for maintaining a fresh and aromatic atmosphere, and its safe, versatile design makes it a great addition to any setting.

Product Features

A. Hanger Hook Design: The design incorporates a practical hanger hook that allows you to easily drape your clothes while using the incense burner. This feature helps in evenly distributing the fragrance while ensuring that your clothes stay wrinkle-free. The hanger also makes it convenient to position your garments without taking up additional space, ideal for larger items like coats, dresses, or traditional attire.

B. Table Tripod Base: The tripod base provides excellent support, ensuring that the incense burner remains upright and stable. The three-legged design helps distribute weight evenly, which is especially important when the burner is in use. Whether you're using it in your home or in a boutique, the tripod ensures the burner won't tip over, providing peace of mind.

C. 186 cm Height: Standing at 186 cm, the burner's height is perfectly suited for hanging clothes of all sizes without the need to bend or adjust them. This height is designed for user convenience, offering enough space to hang longer garments such as long dresses, coats, or robes, making it a versatile addition to any wardrobe or room.

D. Incense Ventilation Holes: These holes are strategically placed to enhance the circulation of the incense smoke and scent. The ventilation ensures that the incense burns efficiently, allowing the aroma to diffuse evenly throughout the room and onto the garments. This feature maximizes the effectiveness of your favorite incense, creating a lasting and pleasant fragrance that helps to eliminate unwanted odors from clothes.

E. Sturdy Non-Skid Base: The burner is equipped with a solid, non-slip base, which prevents it from moving or slipping during use. This feature ensures that the burner stays in place even when there is slight movement or vibrations around it. It's especially beneficial for ensuring the unit doesn't tip over, adding to its overall safety and reliability.

F. Wrinkle Removal & Scenting: The Porodo Clothing Bukhour Incense Burner does more than just infuse your clothes with a lovely fragrance. It helps to gently remove wrinkles by using the heat from the incense to relax the fibers in the fabric. The incense also adds a soothing aroma to your clothes, which makes them smell fresh and clean, as though they've just been freshly laundered or steam-pressed.

G. Versatile & Safe Use: The burner is designed to be safe and easy to use in various environments. Whether you're using it at home to keep your clothes fresh, in your office to eliminate odors, or in a boutique to create an inviting atmosphere, it provides a non-toxic, safe way to care for your clothing. Its versatility also extends to being a great addition to spaces where clothing care is a priority, such as garment shops, tailoring studios, or even luxury hotels.

Operation Guide

1. Set up the Burner:

- a.** Place the Porodo Clothing Bukhour Incense Burner on a flat, stable surface.
- b.** Ensure the non-skid base is in full contact with the floor or table to prevent the burner from moving or tipping over during use.

2. Adjust the Height:

The burner stands at 186 cm, which is ideal for hanging clothes of various lengths.

3. Insert Incense:

- a.** Open the incense holder located at the base of the burner.
- b.** Place your chosen incense in the designated compartment, ensuring it is securely positioned.
- c.** Light the incense with a match or lighter, making sure the incense is burning evenly before proceeding.

4. Ventilation:

- a.** The incense ventilation holes are designed to allow the smoke to circulate freely and disperse the fragrance effectively.
- b.** Position the incense burner in a well-ventilated area to ensure optimal scent diffusion.

5. Allow Wrinkle Removal & Scenting:

- a.** As the incense burns, the heat generated will help remove wrinkles from your clothes.
- b.** The smoke and scent will infuse the fabric, providing a fresh, pleasant fragrance and making your clothes smell clean.
- c.** Depending on the thickness of the fabric, allow 15-30 minutes for the best results.

Safety Precautions

- 1. Never Leave Unattended:** Always monitor the incense burner while it is in use. Never leave it unattended, especially when the incense is burning.
- 2. Keep Away from Flammable Materials:** Ensure the burner is placed on a non-flammable surface, away from curtains, paper, or any other materials that could catch fire.
- 3. Proper Ventilation:** Always use the burner in a well-ventilated area to avoid smoke buildup and ensure a safe, breathable environment. Avoid using it in enclosed spaces without airflow.
- 4. Stable Surface:** Place the incense burner on a flat, stable surface to prevent tipping or movement. Ensure the non-skid base is fully engaged with the floor for added stability.

- 5. Keep Out of Reach of Children and Pets:** Store and use the burner in locations that are not accessible to children or pets to avoid accidents or burns.
- 6. Burn Incense Safely:** Always light the incense carefully and make sure the flame is completely extinguished when you're done. Do not attempt to relight incense once it has burned out.
- 7. Allow Cooling Before Handling:** After use, let the burner cool down before touching it or moving it. This helps to avoid burns from hot surfaces.
- 8. Proper Storage:** When not in use, store the burner in a dry, safe location, away from heat sources and direct sunlight. Ensure the incense holder is clean and free of residue.
- 9. Avoid Overloading Incense:** Only use the recommended amount of incense in the burner's compartment to prevent excess smoke or potential fire hazards.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**