

PORODO *Blue*



Porodo Blue
FlexiTripod
SELFIE STICK

SKU: PBS03SSTBK



Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Product Design	3
Remote Control Battery	3
Remote Control Instructions	4
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Porodo Blue FlexiTripod Selfie Stick is a versatile 3-in-1 device designed for effortless photo and video capture. It features a wireless remote shutter that allows you to snap photos remotely from up to 10 meters away, ensuring you're always part of the shot. The integrated tripod stand offers stable support for hands-free shooting, making it perfect for group photos, vlogs, or live streaming. Its compact and lightweight design, weighing only 115g, makes it easy to carry on the go, while the extendable length of up to 680mm ensures you can capture wide or creative angles with ease. The holder fits smartphones ranging from 3.5 to 6.2 inches and supports 360° rotation, allowing flexible adjustments for the perfect frame every time. Whether you're traveling, creating content, or just capturing memories, this selfie stick combines convenience, portability, and performance in one sleek design.

Specifications


Bluetooth Version	4.0
Wireless Range	10m
Material	Stainless Steel
Battery	CR1632 (Included)
Android System	Android 4.4+
iOS System	iOS 5.1+
Device Compatibility	3.5" - 6.2"
Expanded Height	67.8cm
Product Size	3.2 x 4.7 x 18.4mm
Product Weight	110.9g
Model Number	PBS03SST

Product Features


- A. Wireless Remote Shutter:** Capture perfect selfies and group shots from up to 10 meters away with a detachable Bluetooth remote.
- B. Integrated Tripod Stand:** Easily switch from handheld mode to tripod mode for stable video recording and hands-free photography.
- C. 360° Rotation:** Enjoy full flexibility to adjust your phone's angle horizontally or vertically for the best framing.
- D. Compact & Lightweight:** Weighing only 111g, it's easy to carry and perfect for travel, vlogging, or daily use.
- E. Extendable Design:** Reaches up to 678mm, allowing wider shots and creative angles.
- F. Universal Compatibility:** Fits smartphones from 3.5" to 6.2", ensuring a secure grip for most devices.
- G. Foldable & Portable:** Sleek design folds down for easy storage in your bag or pocket.

Product Design


1. Separable Remote control
2. Camera Button



Remote Control Battery



1. Separate the product from the side of the remote control.



2. After replacing the battery, put the lid back on.

Remote Control Instructions

1. Power On

Long press the remote button to power on. The LED indicator will start blinking.

2. Bluetooth Pairing

On your phone, search for and pair with the Bluetooth device named "PBS03SST."

Once successfully connected, the LED indicator will stop flashing.

Use the remote to capture photos – the LED will flash once each time a picture is taken.

3. Auto Shut Down (Unpaired)

If not paired, the remote control will automatically power off after 5 minutes.

4. Sleep Mode

If inactive for 10 minutes, the remote will enter sleep mode.

It will automatically power off after an additional 10 minutes if not reactivated.

5. Power Off

Long-press the remote button to power off. The LED indicator will flash three times before shutting down.

NOTE: The wireless selfie stick tripod uses a remote control to take photos instead of tapping your cellphone's camera app. It is compatible with both Android and iOS smartphones.

For Android phones only: Set your volume key function to "capture" in the camera app settings for the selfie stick to operate properly.

Safety Precautions

1. Store batteries in a dry and cool place, away from direct sunlight and heat sources.

2. Do not stack or jumble batteries together to prevent short-circuiting.

3. Avoid heating the batteries or exposing them to fire.

4. Do not immerse batteries in water or other liquids.

5. Do not attempt to recharge non-rechargeable batteries.

- 6.** Avoid short-circuiting the battery terminals. Always check and align the positive (+) and negative (-) sides correctly.
- 7.** Do not dispose of batteries in household trash. Dispose of used batteries responsibly according to local recycling regulations.
- 8.** Keep batteries out of reach of children to prevent accidental ingestion or injury.
- 9.** Do not use batteries that are swollen, leaking, or damaged.
- 10.** If battery fluid comes into contact with skin or eyes, rinse immediately with plenty of water and seek medical attention.
- 11.** When replacing the battery, use only the specified type (CR1632) to avoid malfunction or risk of explosion.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**