



Porodo Soundtec

Gala Lite Portable GRB Speaker

SKU: PDSTGW40BBK

Table of Contents

Product Overview	2
Specifications	2
Package Contents	3
Schematic View	3
Product Features	3
Operation Instructions	4
Charging Guidelines	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo Soundtec Gala Lite Portable RGB Speaker delivers 24W immersive stereo sound with deep bass and clear treble. It features dynamic RGB lighting that syncs with the music, a portable handle for easy carrying, and multi-function control for managing playback, volume, and lighting. With up to 6.5 hours of playtime, this speaker is perfect for on-the-go entertainment.

Specifications


Battery Capacity	3600mAh
Rated Power	24W
Playtime	6.5h (50 %Volume), 2.5h (100 %Volume)
Recharge Time	5h
Bluetooth Version	5.3
Bluetooth Range	10m
Frequency Response	80Hz-16kHz
Product Size	99 × 129 × 305mm
Model Number	PDSTGW40B

Package Contents

- Portable Bluetooth Speaker ×1
- Type-C Charging cable ×1
- Battery for microphone × 1
- Wireless Microphone ×1

Schematic View

1. Power Button
2. Light Button
3. Mode Button
4. Play/Pause Button
5. Forward/Volume Up
6. Backward /Volume Down
7. USB port
8. Reset Port
9. Type-C Charging Jack



Product Features

1. A2DP Bluetooth: Enables wireless music streaming from any Bluetooth-enabled device for easy connectivity.
2. Built-in 3600mAh rechargeable lithium battery: Provides long playtime, allowing you to enjoy music without frequent recharging.
3. FM radio function: Allows you to listen to your favorite radio stations for additional entertainment options.
4. Karaoke function with single microphone input: Supports a wireless microphone for karaoke, making it ideal for parties or gatherings.
5. Dynamic RGB lighting: Creates colorful lighting effects that sync with the music, enhancing the listening experience.
6. Strong carry handle: Provides easy portability, making it convenient to take the speaker with you on the go.

Operation Instructions

1. Bluetooth Mode Instructions

Bluetooth Name (Gala_Lite): The Bluetooth name for this speaker is "Gala_Lite." When pairing with your device, search for "Gala_Lite" in the Bluetooth settings.

1-1. Power Button (): Press and hold to turn the speaker on or off.

1-2. Mode Button (): Press briefly to switch between different playing modes.

1-3. Play/Pause Button (): Press briefly to play or pause music. Press and hold to pair or disconnect Bluetooth.

1-4. Backward/Volume Down Button (): Press briefly to decrease the volume. Press and hold to skip to the previous track.

1-5. Forward/Volume Up Button (): Press briefly to increase the volume. Press and hold to skip to the next track.

1-6. Light Button (): Press briefly to switch between different light modes. Press and hold to turn the lights on or off.

2. FM Mode Instructions:

2-1. Power Button (): Press and hold to turn the speaker on or off.

2-2. Mode Button (): Press briefly to switch between different playing modes.

2-3. Play/Pause Button (): Press briefly to mute the sound. Press and hold to automatically search for and store FM channels.

2-4. Backward/Volume Down Button (): Press briefly to decrease the volume. Press and hold to go to the previous FM channel.

2-5. Forward/Volume Up Button (): Press briefly to increase the volume. Press and hold to go to the next FM channel.

3. USB Mode Instructions:

3-1. Power Button (): Press and hold to turn the speaker on or off.

3-2. Mode Button (): Press briefly to switch between different playing modes.

3-3. Play/Pause Button (): Press briefly to play or pause the music.

3-4. Backward/Volume Down Button (): Press briefly to decrease the volume. Press and hold to go to the previous song.

3-5. Forward/Volume Up Button (): Press briefly to increase the volume. Press and hold to go to the next song.

3-6. Light Button (): Press briefly to switch between different light modes. Press and hold to turn the lights on or off.

Notes: When a USB disk is inserted, the speaker will automatically switch to USB mode and begin playing the content from the USB disk, regardless of the current playing mode.

4. Wireless Microphone Use:

4-1. When the speaker is powered on in Bluetooth mode and the wireless microphone is turned on, they will automatically connect if within range.

4-2. Once the connection is established, the blue light on the microphone will remain on, indicating that it is ready for use.

5. Wireless Microphone Operation:

5-1. Ensure the speaker is powered on in Bluetooth mode and the wireless microphone is also turned on.

5-2. The microphone will automatically connect to the speaker when within range.

5-3. After a successful connection, the blue light on the microphone will stay on, indicating it is ready for use.

6. Reset Function

6-1. If the speaker is not responding, use a small round pin to press the "RESET button" to turn off the device.

6-2. To reset the speaker to factory settings, press and hold the "Volume Down button (≡)" for 5 seconds. This will power off the device, clear Bluetooth memory, and restore default settings.

Charging Guidelines

1. The charger is not included in the package. Please charge the speaker with a rated 5V/1A charger or through a PC.

2. Charging time is approximately 5 hours.

3. This unit does not have a power bank function. Do not charge other devices or connect them via the USB port.

4. To protect the battery, avoid using the speaker while it is charging.

Warning

- a.** Please store and use this product in an environment of normal temperature.
- b.** Please do not expose this product to rain or moisture environment.
- c.** Please do not disassemble, repair or modify this product by yourself without authorization.
- d.** When cleaning this product, please use a soft cloth or with little water if needed, please do not use chemicals for cleaning.
- e.** In order to have an extended product life and protect your hearing, please avoid listening to songs on maximum volume for long time.
- f.** The product is with built-in lithium battery, to avoid dangers, please do not discard or put it in the fire.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**