



**Porodo Soundtec**

**CHIC TRUE WIRELESS  
ENC Earbuds**

SKU: PDSTYX66

# Table of Contents

|                                 |   |
|---------------------------------|---|
| Product Overview                | 2 |
| Specifications                  | 2 |
| Usage Instructions              | 3 |
| Charging Indicator Instructions | 4 |
| Safety Precautions              | 4 |
| Disposal                        | 5 |
| Warranty                        | 6 |
| Contact Us                      | 6 |

## Product Overview

The Porodo Soundtec Chic True Wireless ENC Earbuds deliver high-quality sound with an enhanced experience thanks to their Environmental Noise Cancellation (ENC) technology, which reduces background noise for clearer audio during calls and music playback. These earbuds feature an omnidirectional microphone that captures your voice from any angle, ensuring crystal-clear communication. With automatic pairing, the earbuds seamlessly connect to your devices, offering hassle-free use. The immersive audio technology ensures deep and rich sound, enhancing every listening experience. Their ergonomic fit ensures comfort during long listening sessions, and the touch control feature allows for easy operation. With a playtime of 4.5 hours, these earbuds are a perfect blend of functionality and style.

## Specifications

|                       |           |
|-----------------------|-----------|
| Model                 | PDSTYX66  |
| Charging Input        | 5V/300mA  |
| Battery Case Capacity | 230mAh    |
| Earbuds Capacity      | 25mAh     |
| Bluetooth Version     | V5.4      |
| Talk Time             | 2.8 hours |
| Music Playtime        | 4.5 hours |

|                    |                       |
|--------------------|-----------------------|
| Recharge Time      | ≤1 hour               |
| Transmission Range | 10 meters             |
| Frequency Range    | 2.402-2.480 GHz       |
| Net Weight         | 39.26g                |
| Product Dimension  | 29.65 x 55.5 x 60.6mm |

## Usage Instructions

- 1.** Bluetooth Name: YX66
- 2.** Before Use: Remove the earphones from the charging case after unpacking.
- 3.** Pairing Connection:
  - a.** Open the charging case and take out both earphones.
  - b.** Wait 3–5 seconds for automatic pairing between the earbuds.
  - c.** On your device, open Bluetooth settings, search for “YX66”, and tap to connect.
- 4.** Power On: The earphones will automatically power on and reconnect to the last paired device when removed from the open charging case.
- 5.** Power Off: Place the earphones back into the charging case and close the lid. They will automatically power off and begin charging.
- 6.** Volume Control:
  - a.** Increase Volume: Long-press the right earphone’s touch sensor.
  - b.** Decrease Volume: Long-press the left earphone’s touch sensor.
- 7.** Music Control:
  - a.** Next Track: Triple-tap the right earphone.
  - b.** Previous Track: Triple-tap the left earphone.
  - c.** Play/Pause: Single-tap either earphone.

## 8. Call Control:

- a. Answer/Hang Up: Single-tap either earphone.
  - b. Reject Call: Double-tap either earphone during an incoming call.
9. Voice Assistant: Double-tap either earphone to activate your device's voice assistant.

## Charging Indicator Instructions

- 1. When the charging case is charging the earphones, a white light will turn on. The light turns off when fully charged.
  - 2. When the charging case is charging via a cable, an orange light flashes. The orange light stays on when fully charged.
- NOTE:** Please ensure to use a 5V/1A charging cable or the attached charging cable when purchasing products.

## Safety Precautions

- 1. Ensure the headset is correctly positioned for charging.
- 2. The battery (or combination battery pack) should not be exposed to extreme conditions such as direct sunlight, fire, or overheating.
- 3. Listening to music at high volumes for prolonged periods can cause hearing damage. Please adjust the volume to a safe level while using the device.
- 4. Avoid using the device during thunderstorms, as they may cause abnormal operation and increase the risk of electric shock.
- 5. Do not dismantle or modify the headset for any reason, as this may cause malfunction or damage, which is not covered under warranty.
- 6. For optimal performance, store the headset in a dry, cool place when not in use.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**