

PORODO
LIFESTYLE



Porodo Lifestyle

**HANDHELD
MINI PRESS STEAM IRON**

SKU: PDLFST215BG

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Product Design	4
Safety Precautions	5
Adding Water	5
Usage Instructions	6
Steam Discharge Angle	7
Certifications	8
Disposal	8
Warranty	9
Contact Us	9

Product Overview

The Porodo Handheld Mini Press Steam Iron is designed for versatile and efficient garment care. It offers 180° flexibility for multi-angle ironing, making it ideal for both horizontal and vertical steaming. With three adjustable ironing modes, you can customize your settings based on fabric type. The 60mL water tank ensures enough steam for continuous use, while the 1000W powerful steam system provides fast preheat and consistent performance. The iron is equipped with edge-tip access, allowing easy handling of hard-to-reach areas, and its gentle fabric care ensures that your clothes are protected during the ironing process. Perfect for quick touch-ups or detailed steaming, this portable mini iron makes it easy to maintain your clothes on the go.

Specifications

Rated Voltage	220V~240V
Rated Frequency	50/60Hz
Rated Power	1000W
Preheat Time	25-30 Seconds
Water Tank Capacity	60mL
Power Cord	UK 3-Pin
Cord Length	1.35m
Product Size	65 x 70 x 270mm
Model Number	PDLFST215

Product Features

A. 180° Flexibility & Multi-Angle Ironing:

The iron's head can rotate up to 180°, allowing you to iron from various angles. This flexibility makes it easier to iron hard-to-reach areas, such as collars, seams, and cuffs, ensuring a more thorough and efficient ironing process.

B. Three-Mode Ironing:

The mini press offers three different ironing modes, giving you the flexibility to adjust the steam and heat settings according to the fabric you're working with. Whether you're ironing delicate silk or heavy cotton, these modes optimize performance for each fabric type.

C. 60mL Water Tank Capacity:

A compact 60mL water tank allows for convenient steaming without frequent refills. The moderate capacity strikes a balance between performance and portability, making it suitable for both quick touch-ups and longer ironing sessions.

D. Fast Preheat:

The steam iron heats up quickly, reducing waiting time. This feature is perfect for users who need to iron garments in a hurry, enabling a faster and more efficient ironing experience with minimal downtime.

E. 1000W Powerful Steam:

With 1000W of power, this steam iron generates a strong and consistent steam output. This ensures that wrinkles are easily smoothed out, even in thicker fabrics, helping you achieve a crisp and professional finish with less effort.




F. Edge-Tip Access:

The iron's precise edge-tip design makes it easy to target and steam delicate areas like button holes, pleats, and hems. This feature allows for fine-tuned steam distribution, ensuring every corner of your fabric receives attention.

G. Gentle Fabric Care:

The Porodo steam iron is designed to handle various fabrics gently, ensuring that even the most delicate materials, like wool and silk, are not harmed. The controlled steam output and temperature prevent fabric burns or damage, offering peace of mind when working with sensitive clothes.

Product Design





Safety Precautions


- 1. Cool Before Storing:** Do not store the product until it is completely cooled to avoid burns or property damage.
 - 2. Proper Storage:** Avoid storing the power cord in a twisted state, as it may lead to breakage, electric shock, or fire due to a short circuit.
 - 3. Avoid Contact with Hot Parts:** During use, do not touch hot parts (head, bottom plate, surfaces, and high-temperature components).
 - a.** Do not place your hands, feet, etc., under the clothing while ironing.
 - b.** Do not place the product on your hands, knees, or other body parts.
 - c.** Do not iron clothes directly on your body.
 - 4. Steam Safety:** When using the product, avoid steam or water contact with your body, as this may cause burns.
 - 5. Empty Water Tank After Use:** Always empty the water tank after use to prevent hot water from spilling during the next use, which can cause burns.
 - 6. Disconnect Power:** Ensure the power plug is disconnected when adding water to the tank, cleaning, or storing the product.
 - 7. Specialty Fabrics:** When ironing delicate or treated fabrics (velvet, acrylic, nylon, cashmere, etc.), test an inconspicuous area first or use a cloth to prevent direct contact, as high temperatures may cause marks.
- NOTE:** Always check for the "low temperature ironing" label or dark clothing that may be damaged by high heat.

Adding Water

- 1. Adding Water to the Tank**
 - a.** Unplug the appliance from the socket before filling the water tank.
 - b.** Use distilled or pure water for filling the tank. Avoid tap water or mineral water with high mineral content, as it may affect the product's performance.
 - c.** Fill the tank to the MAX water level indicated on the filling cup (approx. 60 mL). Tilt the product body slightly (about 30°) when filling to ensure proper water flow.
- 2.** Close the water outlet cover carefully. Ensure that the water injection cap is positioned as shown, with the product tilted at a 30° angle.



Usage Instructions



1. Preparation:

Hang the clothes to be ironed on a hanger, or lay them flat.

2. Power On:

Plug in the power supply. The indicator light will turn on, and the preheating process will begin.

3. Preheat:

Wait for about 30 seconds. Once the flashing stop light appears, you can select the desired steam setting.

NOTE: The maximum opening angle of the product is approximately 13° . Ensure the handle is gripped tightly to avoid any potential damage during use.

4. Rotation and Steam Settings:

A. Rotate the bottom plate in the direction marked on the top surface of the ironing head. Be careful not to touch the bottom plate height when rotating to avoid damage.


B. The first gear is for heating without steam.

C. The second gear (small steamer, 12-16g) produces steam for up to 8 minutes with a full water tank.

D. The third gear (large steamer, 16-29g) produces steam for up to 4 minutes with a full water tank.

E. Always rotate the device 180° in the direction of the rotation arrow to prevent damage.

F. Do not rotate the iron head in the opposite direction, as this could cause product damage or injury.



G. Switch the product to the auxiliary panel for assisted ironing. Press the lock button first, then turn the dial in the direction indicated. Ensure the upper and lower parts are properly closed. The buckle should secure the product tightly.

H. Initially, the product may not emit steam immediately and may produce some noise. This is normal.

J. Before adding water, always remove the power plug first.

K. When placing the product for heating, ensure the gear is set to the first gear and that the locking buckle is securely fastened before positioning the product flat.

L. When replacing clothes or placing items for use, adjust the gear to the first position, and ensure the locking buckle is firmly locked before placing the product flat.

5. After use, set the gear adjustment to the first gear and pull out the plug to disconnect the power supply.

NOTE: If the water tank does not supply water, it may cause a situation where steam is not emitted.

Steam Discharge Angle

If water or steam is weak or leaking, wait for about 1 minute.

Note:

a. Press the gear adjustment switch to dry, hot, low gear, or high gear.

b. When holding the handle, do not block the air hole of the water injection plug, as this may prevent steam from coming out.



Certifications

1. CPSC & Cal Prop 65 total lead test for all accessible material, limit: 90/100PPM
2. Cal Prop 65 Phthalate8P (BBP / DBP / DEHP / DnOP / DINP / DIDP / DNHP/DIBP) for all accessible material, limit: 1000PPM
3. FCC SDOC

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**