porodo | CHOOSE THE BEST

USER MANUAL

CRYSTAL SHELL
ULTRA-SLIM KEYBOARD

PD-TRPBTKB-BK

Packing List

1. Transparent smart keyboard x 1
2. Keyboard manual x 1
3. Type-C Charging Cable x 1

Connection

When using the keyboard for the first time, please charge it for 3-4 hours to ensure sufficient power.
1. Turn on the keyboard power: Keep pressing the keyboard power button for 3 seconds. (CHRG light shows red and turns on for 3 second, then turns off)
2. Open Windows Settings - Devices - Bluetooth & Other Devices-Add Bluetooth or Other Devices- Bluetooth. Search for "Porodo Crystal KB " and click to connect.
3. Your device is ready to go and the PAIR light turns off. If the keyboard is not used for 10 minutes, it will automatically enter sleep mode. Press any key and wait for 2 to 3 seconds for the device to reconnect automatically.
4. This keyboard could connect three devices, follow below instrations. Press "Fn+1" for 3s, the indicator light will flash, follow the above steps to connect device 1; press "Fn+2" for 3s to connect device 2; press "Fn+3" for 3 seconds to connect device 3.

Specification

Operating voltage	3.0-4.2V	Sleep current	<40uA
Length of operation	Backlit ≤5 hours Not Backlit ≤50 hours	Working current	Backlight ≤85-120mA No Backlight ≤6-10mA
Stand-by current	≤1mA	Low battery alarm	3.0-3.3V
Battery capacity	About 500mAh	Standby time	≤ 180 Days
Button life	3 million taps	Battery Life	2 Years
Connection distance	≤10m	Keystroke	50-70g
Recharging current	≤250mA	Charging port	Type C Interface
Reconnect time	2-3 seconds	Charging time	2-3 hours
Pairing password	No	Wake-up time	≤ 3 Seconds
Number of keys	78 keys	Operating temperatu	-10°C - 55°C

Keyboard Features

Keyboard Overview:



Backlit Instruction:
1. Make sure the keyboard is connected to the device.
2. Single press the backlight key to switch the 3 levels of backlight brightness.
3. Press the and or keys to switch between seven colors to adjust the backlight color.
4. When the battery power is lower than 20%, the backlight turns off by itself and should not be turned on.
5. Power on without any device connected, the keyboard enters breathing mode, 7-color cycle;
6. The pairing is successful and the breathing is closed, and the keyboard has no backlight at this time;
7. FN+RGB key: turn on or off breathing mode;
8. RGB key: turn on the backlight and switch the backlight brightness;
9. RGB key + up ↑ (PageUp) or down ↓ (PageDown): switch seven-color backlight;
10. The keyboard goes to sleep in ten minutes, records the state of the backlight during sleep, and restores the state of the backlight before sleep when it wakes up;
11. Low voltage automatically turns off the backlight. (For example, after the backlight is automatically turned off, you need to manually turn on the backlight when the battery is restored)

Note: You can change the brightness and switch colors only when the backlight is always on.

Charge:
1. For the first use, please use the included charge cable to fully charge the keyboard (CHRG ligth turns green).
2. When charging, please check whether the charging port is powered normally.
Note: Please do not charge the keyboard for a long time. Keeping it plugged in for a long time will deplete the keyboard's battery life.

Cleaning & Care for the Keyboard
To keep your keyboard looking and working great, please maintain good usage habits and pay attention to protecting the keyboard.

Keyboard and Outer Cover Care
The keyboard is relatively thin and light. Please be careful not to use it on uneven surfaces to avoid bending the keyboard. Don' t apply liquids directly to the keyboard. Cleanoften in this way to keep your keyboard cover looking great.

Battery Care Operating temperature:
Keyboard is designed to work between 0°C to 35°C. Lithium batteries are sensitive to high temperatures, so keep your Surface out of the sun and don' t leave it in a hot car. Recharge anytime: The battery doesn' t need to be empty or low before you recharge. You can recharge the battery whenever you like. However, do not keep charging for a long time, it will decrease the battery life.

Troubleshooting

1. Why is my smartphone/tablet unable to find the keyboard in the Wireless search screen ?
Please make sure you have pressed the connect button. You should see the status blinking in Blue. If the LED isn't blinking, your device won't find it.

2. Why can't I type in Spanish,Japanese or other languages?
The languages input setting is on your tablet. Our keyboard are standard US English and you will see there are only English letters printed on each button. If your device supports Spanish, the keyboard can also type in Spanish, but the position or some keys may be different.

3. Why can't I type when the keyboard is paired?
Please check the Input setting on your device to make sure all of the settings are set to ON status. If not, please turn them on.
Please kindly contact us timely if you meet with any problems, we will solve to you ASAP.

For more information, please contact our support team:
support@porodo.net

Made in China

www.porodo.net /porodo /myporodo

porodo | CHOOSE THE BEST

USER MANUAL

لوحة مفاتيح
بلورية فائقة النحافة

PD-TRPBTKB-BK

قائمة التعبئة

١. لوحة مفاتيح ذكية شفافة × ١
٢. دليل لوحة المفاتيح × ١
٣. كابل شحن تايب-سي × ١

كيفية الاتصال

عند استخدام لوحة المفاتيح للمرة الأولى ، يرجى شحنها لمدة ٣-٤ ساعات لضمان الطاقة الكافية.
١. قم بتشغيل طاقة لوحة المفاتيح: استمر في الضغط على زر تشغيل لوحة المفاتيح لمدة ٣ ثوان. (يظهر ضوء CHRG باللون الأحمر ويتم تشغيله لمدة ٣ ثوان ، ثم ينطفئ)
٢. افتح إعدادات ويندوز - الأجهزة - بلوتوث والأجهزة الأخرى - أضف بلوتوث أو أجهزة أخرى - بلوتوث. ابحث عن "Porodo Crystal KB" وانقر للاتصال.
٣. جهازك جاهز للانطلاق وينطفئ ضوء الزوج. إذا لم يتم استخدام لوحة المفاتيح لمدة ١٠ دقائق ، فسوف تدخل تلقائيًا في وضع السكون. اضغط على أي مفتاح وانتظر لمدة ٢ إلى ٣ ثوانٍ حتى يقوم الجهاز بإعادة الاتصال تلقائيًا.
٤. يمكن توصيل لوحة المفاتيح بثلاثة أجهزة ، اتبع التعليمات أدناه. اضغط على "Fn + 1" لمدة ٣ ثوانٍ ، سيصبح ضوء المؤشر رماداً ، اتبع الخطوات المذكورة أعلاه لتوصيل الجهاز ١ ؛ اضغط على "Fn + ٢" لمدة ٣ ثوانٍ لتوصيل الجهاز ٢ ؛ اضغط على "Fn + ٣" لمدة ٣ ثوان لتوصيل الجهاز ٣.

المواصفات

جهد التشغيل	٣.٠-٤.٢ فولت	النوم الحالي	<٤٠uA
مدة العملية	الخلفية ≤٥ ساعات غير مضاءة من الخلف ≤٥٠ ساعة	التشغيل الحالي	الإضاءة الخلفية ≤٨٥-١٢٠ مللي أمبير لا الخلفية ≤١-١٠ مللي أمبير
الاستعداد الحالية	≤١ مللي أمبير	إنذار البطارية المنخفضة	٣.٠-٣.٣ فولت
قدرة البطارية	حوالي ٥٠٠ مللي أمبير	وقت الاستعداد	≤١٨٠ يومًا
عمر الزر	٣ ملايين نقرة	عمر البطارية	سنتان
مسافة الاتصال	≤١٠ م	كمية الضغطات	٥٠-٧٠ جم
إعادة الشحن الحالية	≤٢٥٠ مللي أمبير	منفذ الشحن	واجهة تايب-سي واحدة
أيد توصيل الوقت	٢-٣ ثوانٍ	وقت الشحن	٢-٣ ساعات
كلمة مرور الإقران	لا	وقت الاستيقاظ	≤٣ ثوانٍ
عدد المفاتيح	٧٨ مفتاحًا	درجة حرارة التشغيل	-١٠ درجة مئوية - ٥٥ درجة مئوية

ميزات لوحة المفاتيح

نظرة عامة على لوحة المفاتيح:



تعليمات الإضاءة الخلفية:
١. تأكد من توصيل لوحة المفاتيح بالجهاز.
٢. اضغط مرة واحدة على مفتاح الإضاءة الخلفية للتبديل بين المستويات الثلاثة لسطوع الإضاءة الخلفية.
٣. اضغط على مفتاحي و أو للتبديل بين سبعة ألوان اضبط لون الإضاءة الخلفية.
٤. عندما تكون طاقة البطارية أقل من ٢٠٪ ، تنطفئ الإضاءة الخلفية من تلقاء نفسها ولا يجب تشغيلها.
٥. التشغيل بدون توصيل أي جهاز ، تدخل لوحة المفاتيح في وضع التنفس ، دورة ٧ ألوان ؛
٦. تم الاقتران بنجاح وتم إغلاق الاضوء ، ولا توجد إضاءة خلفية في لوحة المفاتيح في هذا الوقت ؛
٧. FN + RGB مفتاح: تشغيل أو إيقاف تشغيل وضع التنفس ؛
٨. مفتاح RGB: قم بتشغيل الإضاءة الخلفية وقم بتبديل سطوع الإضاءة الخلفية.
٩. مفتاح RGB + أعلى↑(صفحة لأعلى) أو لأسفل↓(صفحة لأسفل): تبديل الإضاءة الخلفية بسبعة ألوان ؛
١٠. تذهب لوحة المفاتيح للنوم خلال عشر دقائق ، وتسجل حالة الإضاءة الخلفية أثناء النوم ، وتستعيد حالة الإضاءة الخلفية قبل النوم عند الاستيقاظ.
١١. الفولتية المنخفضة تغلق الإضاءة الخلفية أوتوماتيكياً. (على سبيل المثال ، بعد إيقاف تشغيل الإضاءة الخلفية تلقائيًا ، تحتاج إلى تشغيل الإضاءة الخلفية يدويًا عند استعادة البطارية)
ملاحظة: يمكنك تغيير السطوع وتبديل الألوان فقط عندما تكون الإضاءة الخلفية قيد التشغيل دائمًا.

الشحن
١. للاستخدام الأول ، يرجى استخدام كابل الشحن المرفق لشحن لوحة المفاتيح بالكامل (يتحول ligth CHRG إلى اللون الأخضر).
٢. عند الشحن ، يرجى التحقق مما إذا كان منفذ الشحن يعمل بشكل طبيعي.
ملاحظة: من فضلك لا تشحن لوحة المفاتيح لفترة طويلة. سيؤدي استمرار توصيله بالكهرباء لفترة طويلة إلى استنفاد عمر بطارية لوحة المفاتيح.

التنظيف والعناية بلوحة المفاتيح
للحفاظ على مظهر لوحة المفاتيح وعملها بشكل رائع ، يرجى الحفاظ على عادات الاستخدام الجيدة والاهتمام بحماية لوحة المفاتيح.

لوحة المفاتيح والعناية بالغطاء الخارجي
لوحة المفاتيح رقيقة وخفيفة نسبيًا. يرجى الحرص على عدم استخدامه على الأسطح غير المستوية لتجنب ثني لوحة المفاتيح. لا تضع السوائل مباشرةً على لوحة المفاتيح. قم بالتنظيف بهذه الطريقة للحفاظ على مظهر غطاء لوحة المفاتيح الخاص بك رائعًا.

العناية بالبطارية درجة حرارة التشغيل:
لوحة المفاتيح مصممة للعمل في درجات حرارة تتراوح بين ٠ درجة مئوية و ٣٥ درجة مئوية. بطاريات الليثيوم حساسة لدرجات الحرارة المرتفعة ، لذا احرص على إبقاء السطح بعيدًا عن أشعة الشمس ولا تتركه في سيارة ساخنة. إعادة الشحن في أي وقت: ليس من الضروري أن تكون البطارية فارغة أو منخفضة قبل إعادة الشحن. يمكنك إعادة شحن البطارية متى شئت. ومع ذلك ، لا تستمر في الشحن لفترة طويلة ، فهذا سيقلل من عمر البطارية.

استكشاف الأخطاء وإصلاحها

لماذا يتعذر على هاتفي الذكي / الكمبيوتر اللوحي العثور على لوحة المفاتيح في شاشة البحث اللاسلكي؟
يرجى التأكد من الضغط على زر الاتصال. يجب أن ترى الحالة تومض باللون الأزرق. إذا كان مؤشر LED لا يومض ، فلن يعثر عليه جهازك.

٢. لماذا لا يمكنني الكتابة بالإسبانية أو اليابانية أو لغات أخرى؟
إعداد إدخال اللغات موجود على جهازك اللوحي. لوحة المفاتيح لدينا هي المعيار الإنجليزية الأمريكية وسترى أنه توجد أحرف إنجليزية فقط مطبوعة على كل زر. إذا كان جهازك يدعم اللغة الإسبانية ، فيمكن أن تكتب لوحة المفاتيح أيضًا باللغة الإسبانية ، ولكن قد يختلف الموضع أو بعض المفاتيح.

٣. لماذا لا يمكنني الكتابة عند إقران لوحة المفاتيح؟
يرجى التحقق من إعداد الإدخال على جهازك للتأكد من ضبط جميع الإعدادات على حالة التشغيل. إذا لم يكن كذلك ، يرجى تشغيلها.
يرجى التكرم بالاتصال بنا في الوقت المناسب إذا واجهت أي مشاكل ، وسنحل لك في أسرع وقت ممكن.

لمزيد من المعلومات ، يرجى الاتصال بفريق الدعم لدينا:
support@porodo.net

Made in China

www.porodo.net /porodo /myporodo