

porodo



Porodo Blue
Nebula Smart Watch Black dial
with Black Silicone Band

SKU: PD-NEBULA-BK

Thank you for selecting our smartwatch. By consulting this manual, you'll gain a comprehensive understanding of this product's operation. Primarily, this device establishes connectivity with your mobile phone via Bluetooth for seamless integration and utilization. It offers an array of practical features and services to streamline your mobile phone operations, including various functions related to human movement and health. It's essential to emphasize that this product is NOT a medical device. Any health data and recommendations provided are intended for reference purposes only and should not be considered as diagnostic results.

Instructions for Use

Upper right key: Single-press to access the menu interface, single press to return to the previous level interface while in other application interfaces, and double press to switch the menu style within the menu interface.

Bottom right button: Long-press the button to power the device on and off, click to turn off the screen when powered on, and click to return to the main interface from the menu function interface.

Dial switch: The rotary encoder controls the dial switching function.

App Connectivity

Download and install the "FereFit" app on your phone to connect with the watch.

1. For iOS or Android users, scan the provided QR code using your phone's browser to open the interface and proceed with the setup. A QR code is provided below for direct access to the "FereFit" app download.



Android / IOS

2. Alternatively, search for "FereFit" in the App Store or the Google Play. Download and install the app.

Note: You will encounter several permission requests throughout the installation phase. It is imperative that you select "Agree" for each prompt to proceed. The watch must be connected via two Bluetooth connections, versions 3.0 and 5.0, to access all features.

3. Bluetooth 5.0 connection method:

Once installation is complete, open "FereFit" app and activate Bluetooth on your phone. The app will prompt you to enable it; click OK to proceed. Tap "More" in the lower right corner, then select "Scan Device" to search for the device name "**Nebula**". Click on the desired address to connect. Note that for some Android phones, turning on the phone's GPS may be necessary to locate the Bluetooth name of the watch.

4. Bluetooth 3.0 connection method:

Activate Bluetooth on the watch 3.0. Enable Bluetooth on your mobile phone, then select the Bluetooth name of the watch you that is "**Nebula**". Follow the prompts to establish the Bluetooth connection, and your mobile phone will display "connected" once successfully paired.

Bluetooth Connection Verification

To verify Bluetooth connectivity, pull up the status bar on the watch's standby interface. If the Bluetooth icons for both 3.0 and 5.0 are blue and green, it indicates a successful Bluetooth connection. Conversely, if the Bluetooth logo appears gray, it signifies that Bluetooth is not currently connected.

Troubleshooting

For common issues, consider these simple solutions: Due to variations in Bluetooth protocols among different mobile phone brands, occasional instability in the Bluetooth connection between the phone and watch may occur. Try turning off Bluetooth on your mobile phone and reconnecting, or resetting the watch to its factory settings.

Setting Up Notifications

Navigate to Settings > Application Management on your phone. Locate "FereFit" and access Permission Management. Ensure all permissions are turned on. Next, enter notification management, find "FereFit", and enable all permissions.

Note: If the WeChat computer version is online simultaneously, notifications may not be received on the mobile phone. Additionally, some mobile phones may require adding "FereFit" to the power-saving white list to prevent it from being shut off by the phone during low battery conditions.

Troubleshooting Notifications

Should you fail to receive a notification, it is important to note that the watch's notification function is an extension of your mobile's notification features, such as calls. If your mobile does not receive a notification, the watch will similarly not receive it. To activate the notification feature, configure the settings within the "FereFit" app to allow the notifications to be displayed.

Function Introduction

Encoder: Rotate the button on the standby interface to switch the dial, and slide up and down in the secondary menu; the star-studded menu can be zoomed in and out. After the interface is maximized, you can enter the application in the middle of the interface.

Dial Push: You can push the pointer dial, digital dial, and custom dial on the APP.

Phone: You can make calls through the watch, view call records, manage contacts, and set incoming calls/buttons to mute or vibrate.

Contacts: You can add contacts to the phone book on the watch through the APP.

Call Records: The call records on the mobile phone can be synchronized.

Dial Keypad: Connect to the mobile phone to dial out, and the call can be realized on the watch side.

Activity Data: You can view the number of steps taken throughout the day, along with historical step counts, calorie consumption, and walking distance. After midnight every night, the interface data will reset to zero.

Information: View messages received on the mobile phone, including support for Facebook, Twitter, WhatsApp, and others.

Music: After connecting, you can control the music playback on your phone.

Heart Rate: Place the watch close to your wrist, ideally above the wrist bone and along the arm, to measure the real-time heart rate.

Blood Oxygen: Measurement will begin as soon as you start the function. Please keep your arm still during the measurement. The value will be available after about 20 seconds.

Blood Pressure: Monitoring starts upon activation. Please keep your hands flat; the measurement will be ready after about 20 seconds.

Body Temperature: Monitoring begins upon activation. Please keep your hands flat, and the temperature reading will be available after about 20 seconds.

Alarm Clock: Up to three alarm clocks can be synchronized through the APP, and settings can also be adjusted directly on the watch.

Voice Assistant (Siri): After connecting via Bluetooth 3.0/5.0, activate the voice assistant on the watch to engage in conversation.

Sleep: The sleep monitoring feature tracks both duration and quality of sleep from 21:00 to 9:00 the following morning. This data helps in personal schedule adjustment and improving sleep quality. Sleep data can be accessed synchronously by connecting to the APP.

Exercise: The watch supports a variety of sports specialties, including running, walking, football, badminton, tennis, basketball, table tennis, cycling, and other sports activities.

Taking Pictures: When the watch is linked to a mobile phone via Bluetooth, you can use it to take pictures. The photos are stored directly in the mobile phone's album.

Find Phone: Connect via Bluetooth and use the watch's interface to locate your phone. The phone will ring until the action is cancelled, and the watch will vibrate continuously until it is found.

Weather: Once connected to Bluetooth, the watch can display the weather forecast for up to four days.

Stopwatch: Activate this function to use the stopwatch for timing single or multiple events.

Breathing: This feature allows you to set the duration and pace of breathing exercises.

Calculator: Use this tool for performing simple calculations.

Menu Style: Customize the watch's menu interface according to your personal preferences.

Settings: Access the system settings to make adjustments.

Component Functions: Swipe right on the watch face to access quick functions such as heart rate monitoring, sleep tracking, weather updates, and music control.

Women's Health Function: Tracks menstrual cycles and predicts ovulation, providing reminders as needed.

Games: Includes the game "The Bird Flies First".

Various Local Settings are Possible: Customize settings according

Additional Settings

Stay on Time: Set and adjust the watch's time display.

Screen Off Time: Set the screen timeout duration as per your preferences.

Raise Your Wrist to Light Up the Screen: Enable or disable the screen to light up when you raise your wrist, according to your needs.

Brightness Adjustment: Access this feature to set the screen brightness.

Do Not Disturb Mode: You can activate 'Do Not Disturb' mode to silence notifications either all day or at scheduled intervals.

Drainage Function: The shaking of the bracelet enhances its drainage capability.

Password Setting: You can set a password for security. If forgotten, enter 8888 to unlock the device.

Connect with Mobile Phone: Scan the QR code with your mobile phone to be directed to the app download page for further setup.

Power Saving Mode: Activate this mode to dim the screen and disable vibration, thereby conserving battery life.

Language Switching: The device supports multiple languages, allowing you to select one based on your preference.

Time Setting: Sync the time with the app or adjust it manually on the device.

Date Setting: Sync the date with the app or set it manually, as preferred.

Restore Factory Settings: Reset the device to factory settings to resolve any software issues.

Shutdown: Power down the device from this menu option.

About: Check the watch model, software version, and MAC address.

Specifications

Size	48×56×15mm
Weight	70g
Major Functions (App/Watch)	Camera, Off, Standby Dial, Cycling; Cell Phone Music, Weather, Dialing, Messaging, Brightness Adjustment; Calendar, Alarm Clock, Oxygen, Pressure, Walking, Restart; Language, Calls (Contacts, Call Logs, Dialing), Pedometer, Exercise (Running, Indoor, Walking, Cycling, Mountaineering, Basketball, Badminton, Soccer, Yoga, Free Exercise, Custom (to delete sports items that have been added)), Heart Rate, Exercise Log, Running; Menu Style (List, Honeycomb, Scroll, Kaleidoscope, Waterfall Flow), Calculator, Blood Pressure, Sleep, Stopwatch, Contact; Do Not Disturb, Find, Settings (Adjust Brightness, Password, Do Not Disturb Mode, Language Switch, Menu Style, System Menu, Standby Dial, Raise Hand to Light Screen, Always Light Time, On), Breathing, Countdown; Resume Factory, On, Voice Assistant, Mountaineering; Under the Menu: Time and Date, Electricity, Weather, Find, Often Bright Settings, Alarm Clock, Brightness Adjustment, Two-Dimensional Code, Settings, Do Not Disturb; Up Menu: Information Right -Swipe, Custom (point "+" can increase, delete, rate, activity, pressure, oxygen, sleep, music, weather, heart, breathing training); Left-Side: Show Right-Swipe Added Content.
APP	FereFit
Compatible System	Android 5.0 and above; IOS 9.0 and above
FLASH memory	128MB
Screen size	1.43"
Resolution	AMOLED 466×466
Touch type	Full Touch Screen
G-Sensor	SC7A20E
Bluetooth Version	BT 3.0/5.0
Bluetooth Name	Nebula

Type	Lithium Polymer Battery
Capacity	3.7V/300mAh
Charging Method	Wireless Charging
APP Language	English (default), Chinese (simplified), Turkish, Russian, Spanish, Italian, Portuguese, German, French, Dutch, Polish, Czech, Hungarian, Slovak, Japanese, Danish, Finnish, Norwegian, Swedish, Serbian, Thai, Hindi and Greek.
Waterproof Level	IP67
Charging Time	2-3H
Operating Time	7-15Days
Wristband Size	Total Length: 257mm, Width: 48mm
Material	Zinc alloy



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**