

PORODO



Porodo

YAS

5000mAh Power Bank

SKU: PDPBFCH0103GY

Table of Contents

| | |
|----------------------|---|
| Product Overview | 2 |
| Specifications | 2 |
| Product Components | 3 |
| Instructions for Use | 4 |
| Safety Precautions | 4 |
| Material Contents | 5 |
| FAQ | 6 |
| FCC Statement | 7 |
| Disposal | 8 |
| Warranty | 9 |
| Contact Us | 9 |

Product Overview


The Porodo YAS 5000mAh Power Bank offers efficient 20W PD fast charging with wireless output and dual USB-C ports, allowing you to charge multiple devices simultaneously. It features a digital LED display to show the remaining battery percentage and is compatible with MagSafe for secure wireless charging. Additionally, the power bank includes a magnetic detachable kickstand for added convenience, making it an ideal portable charging solution.

Specifications

| | |
|-----------------------|-------------------------------------|
| Material | ABS+PC |
| Battery Capacity | 5000mAh |
| USB-C1/C2 Input | 5V/3A, 9V/2A, 12V/1.5A, 18W Max |
| USB-C1/C2 Output | 5V/3A, 9V/2.22A, 12V/1.67A, 20W Max |
| Wireless Output | 5W/7.5W/10W/15W |
| Total Output | 5V/3A, 15W Max |
| Watch Charging Output | 2.5W Max |
| Working Temperature | 0°C to 35°C |
| Cable Lengths | 18.5cm |
| Product Weight | 164g |

| | |
|--------------|-------------------------|
| Product Size | 10.25 x 69.7 x 106.27mm |
| Model Number | PDPBFCH0103 |

Product Components



- 1.** Display
- 2.** Watch Wireless Charging/Wireless Output
- 3.** Type-C1 Input/Output
- 4.** Type-C2 Input/Output
- 5.** Switch Button

Instructions for Use

- 1. Product Usage:** To charge various digital devices, connect them to the power bank using a Type-C cable with the appropriate connector.
- 2. Charging the Power Bank:** When the power bank's battery is low, recharge it by connecting a compatible charging cable to the USB port on a computer, AC adapter, or car charger.
- 3. Recharging the Power Bank**
 - 3.1.** The display lamp shows the current power.
 - 3.2.** Connect the charger and the indicator light will flash during charging. When there is a fast charging input, the first light will light up green, and it will remain on for a long time after being fully charged. Stop charging when fully charged.
 - 3.3. Display status while charging the power bank:**

Insert the device to be charged; automatically, the product will output to charge the device. The indicator light will be on, and when there is a fast charging output, the first charging indicator light will turn green.

Safety Precautions

- 1.** The product should be placed on the desktop during use. If it needs to be in contact with the human body, the contact time should be less than 10 seconds.
- 2.** The working temperature range of the product is 0°C to 35°C (it is recommended to not use it in environments above 35°C or below 0°C).
- 3.** Do not put this product into fire or water, and do not scrub it with a damp cloth to avoid leakage, short circuit, or other malfunctions.
- 4.** Do not use this product if damaged or defective.
- 5.** Do not attempt to disassemble the device by yourself. This product does not have components that can be disassembled or maintained by yourself.
- 6.** Do not drop, shake, knock, impact, or squeeze the product.

7. Please check the product output voltage to ensure it matches the required power for safe charging.
8. Please unplug the charger after fully charged.
9. If there are any irregularities, such as heat, discoloration, deformation, or leakage, please immediately stop using it.
10. If the battery is damaged, do not throw it away casually or expose it to direct sunlight, fire, or environments with high heat. Also, do not dispose of the product in water.

Material Contents

| Declaration of Hazardous Substances in Electronic and Electrical Products | | | | | | |
|---|----|----|----|------|------|-------|
| Component Names | Pb | Cd | Hg | Cr6+ | PBBs | PBDEs |
| Shell | ○ | ○ | ○ | ○ | ○ | ○ |
| PCB | × | ○ | ○ | ○ | ○ | ○ |
| Battery | ○ | ○ | ○ | ○ | × | × |
| Screw | ○ | ○ | ○ | ○ | × | × |
| Metal Components | ○ | ○ | ○ | ○ | -- | - |
| Data line | ○ | ○ | ○ | ○ | ○ | ○ |

This table is prepared in accordance with the provisions of SJ/T11364.

○ : Identify that the content of the toxic and harmful substance in all homogeneous materials of the component is within the limit requirements specified in GB/T 26572.

× : The components marked with X in the table above, which indicate that the toxic and harmful substance exceeds the limit requirements specified in GB/T 26572 in at least one homogeneous material of the component, cannot be replaced due to technical reasons. In the future, with technological progress, replacement or improvement will be achieved.

- : According to GB/T 26572, there are no requirements for the content of PBBs and PBDEs in metal components.



The environmental protection period of this product under normal use is 5 years.

The "hazardous substances" displayed in this table will not cause any harm to human life and the environment under normal use of the product.

The "hazardous substances" and their components displayed in this table are intended to provide consumers and recycling practitioners with information on the presence of relevant substances, which will help with the proper disposal of product waste.

FAQ

| Malfunction | Reasons | Solutions |
|---|--|--|
| The indicators do not show a full charge after charging the product for an extended period. | <ol style="list-style-type: none"> 1. Insufficient charging time. 2. Malfunction of the adapter or product. | <ol style="list-style-type: none"> 1. Charge the product for 12 hours. 2. Contact the distributor or after-sales service. |
| The remaining battery power cannot be detected. | <ol style="list-style-type: none"> 1. No remaining power. 2. Malfunction of the power button or indicator. 3. Power failure of the product. | <ol style="list-style-type: none"> 1. Charge the product again. 2. Contact the distributor or after-sales service. |
| The product cannot charge other devices. | <ol style="list-style-type: none"> 1. Low power of the product. 2. No power transmission through the USB cable or adapter. 3. Incorrect adapter choice. 4. The power management system of the product prevents charging. | <ol style="list-style-type: none"> 1. Charge the product again. 2. Replace the USB cable or adapter. 3. Use a connector that fits the product's interface. 4. The product is incompatible with the device. |
| The product can charge other devices but cannot fully charge them. | The battery of the product is fully used up. | Charge the product. |

| | | |
|--|---|--|
| <p>When charging other devices with the remaining power, the product stops working suddenly or fails to display any power.</p> | <p>External short circuit or overload causes an automatic shutdown for self-protection.</p> | <p>Charge to reactivate the product.</p> |
|--|---|--|

Note:

1. If the product emits an unusual smell, overheats, shows discoloration, deforms, leaks, or exhibits other abnormal conditions during use, stop using it immediately.
2. If the skin comes into contact with battery liquid, wash it off immediately with water and seek medical attention.
3. When not in use, dispose of the product properly.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference; and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements.

The device can be used in portable exposure conditions without restriction.

Disposal

This product must not be disposed of with regular household waste. To ensure proper environmental protection, please separate the product from general waste and dispose of it according to local waste management guidelines. Take the product to an authorized recycling center designated by the government for safe recycling and treatment. This helps promote sustainability and reduces environmental impact.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: <https://www.porodo.net/>

Service Support: **support@porodo.net**

Instagram: **porodo**