

porodo



Smart Watch Ultra **Ultimo**

With Alpine Band & Ocean Band _ SKU:PD-ULTIMO

We appreciate your choice of our smartwatch. This manual offers detailed guidance on utilizing your new device. It seamlessly connects to your cell phone via Bluetooth, offering an array of features that enhance interaction with your phone and support your health and fitness journey. Our commitment is to continual enhancement of these functions for your benefit. Please note that changes to this manual's content may occur without prior notification.

The watch is not waterproof to IP68 standards and is not designed for use in heavy rain, during swimming, in hot showers, or saunas. Exposure to water vapor is also not advised. Damage caused by such exposure is not covered under warranty.

Operating Instructions

Key Functions

- 1. Upper Right Key:** A single press accesses the menu; press again to return to the previous screen or double press to change the menu style in the main interface.
- 2. Lower Right Key:** Hold to power the device on or off; upon starting, tap the screen to access the menu and return to the main interface.
- 3. Left Button:** Short press to activate sports mode; hold to access the button function settings.

Touch Gestures

Swipe left for quick function access; swipe right for split-screen UI. Swipe down for the control center; swipe up for the message bar. After selecting a function, swipe right to return.

Dial Switching: Rotate the dial to switch watch faces.

Strap Replacement: Features a quick-release mechanism for easy installation.

Charging Instructions

Charge by reversing the watch so the charging cable magnetically aligns with the contacts. It is compatible with standard 5V chargers for computers or cell phones.

Caution: The charging cable's contacts must not touch other conductive materials concurrently, as this could cause short-circuiting or damage.

Connecting the Watch to a Cell Phone:

Download and install the "FereFit" app on your phone to connect with the watch.

1. For iOS or Android users, scan the provided QR code using your phone's browser or WeChat to open the interface and proceed with the setup.

A QR code is provided below for direct access to the "FereFit" app download.



Android/iOS

2. Android users can find the app on Google Play or other cell phone application stores by searching "FereFit". iPhone users can search for "FereFit" in the App Store.

Note: During installation, you will encounter various permission requests; please consent to these to ensure full functionality between your watch and phone. The watch must be connected via two Bluetooth connections, versions 3.0 and 5.0, to access all features.

Bluetooth 5.0 Connection:

After installing FereFit, activate your phone's Bluetooth. FereFit will prompt you to enable necessary notifications. To pair, go to the bottom right corner of the app, select the scanning option, look for "Ultimo", and connect. Some Android devices may require GPS activation to pair.

Bluetooth 3.0 Connection:

1. Activate the watch's Bluetooth 3.0.
2. Enable Bluetooth on your phone and select "Ultimo" from the list of devices. Follow on-screen prompts to establish the connection.

Bluetooth Connection Verification:

A successful connection is indicated by the status bar displaying the Bluetooth icon in blue for both 3.0 and 5.0 connections. If the icon turns gray, the Bluetooth link has been lost.

Troubleshooting:

Due to the variance in Bluetooth protocols across different phone brands, the connection may occasionally become unstable. If issues arise, you can toggle the phone's Bluetooth off and on, or reset the watch to its factory settings to resolve the problem.

Setting Up Notifications:

To enable notifications for incoming mail on your smartwatch, navigate to 'Settings' > 'Application Management'. Search for "FereFit" and select 'Permissions Management'. Ensure all permissions are enabled for "FereFit".

Note: If the desktop version of WeChat is active, the phone may not receive notifications. To prevent the watch from being affected by power-saving features, especially when the phone's battery is low, add "FereFit" to the whitelist within the power-saving settings.

Troubleshooting Notifications

If notifications are not being received on the watch, it's important to note that the watch's notification feature is linked with the phone's notification system. This includes notifications for emails, QQ, and WeChat. If notifications aren't appearing, ensure that the corresponding application has notifications enabled in the phone's settings.

Main Function Introduction

Encoder: Rotate the button on the watch's standby interface to switch between dials or navigate up and down in the menu. The full-star style menu can be zoomed for ease of use, and applications can be maximized from within this interface.

Split Screen: Slide to the right in the dial interface to access the split-screen functionality and select the desired function.

Dial Pushing: Customize the dial display through the app, with options for pointer dials, digital, and custom dials.

Phone: Make calls directly from the watch, view call logs, contacts, and manage incoming calls with vibration or sound alerts.

Contacts: Synchronize up to 10 contacts from the phone to the watch via the app.

Call Records: Sync call logs between the watch and phone.

Dialing Keypad: Dial out directly from the watch.

Activity Data: Track daily steps, history, calorie consumption, and distance walked. Data resets at midnight each day.

Message: Receive messages from your phone, including support for various social platforms.

Music: Control music playback from the connected phone via Bluetooth. Only the phone can play music, not the watch.

Heart Rate: For accurate readings, wear the watch close to your wrist, above the bone. Real-time heart rate monitoring is available.

Blood Oxygen: To measure blood oxygen levels, ensure the watch is worn correctly and remain still during measurement. (about 20s)

Blood Pressure: Initiate monitoring by entering the function. For accurate readings, please wrap your hand flat and remain still for approximately 20 seconds.

Body Temperature: Activate the monitoring feature. To begin, place your hand flat and wait around 20 seconds to register the value.

Alarm Clock: Set up to three alarms via the accompanying app. Alarms can also be configured directly on the watch.

Voice Assistant (Siri): After establishing a connection with Bluetooth 5.0/3.0, engage Siri by activating the voice command feature on the watch.

Sleep Monitoring: The device tracks sleep duration and quality from 21:00 until 09:00. This data assists in optimizing your work and rest periods for enhanced sleep quality. Access and manage your sleep records through the app.

Exercise Modes: The watch supports various exercise modes, including running, walking, soccer, badminton, tennis, basketball, table tennis, cycling, and additional sports.

Photo Capture: When the phone is unlocked, connect to the watch via Bluetooth to take photos. Images will be saved directly to your phone's album.

Find Your Phone: By connecting to Bluetooth, utilize the watch to ring your phone until you locate it or cancel the function.

Device Finder: Access this feature via the app to trigger persistent vibrations on the watch until you deactivate it.

Weather Forecast: The watch displays a 7-day weather forecast when connected via Bluetooth.

Stopwatch: Operate the stopwatch for both individual and cumulative timing tasks.

Breathing Exercise: Adjust the duration and pace of breathing exercises to your preference.

Calculator: Utilize the calculator for basic arithmetic functions.

Menu Customization: Select from a variety of menu styles to suit your personal preference.

Settings: Access the system settings to customize your experience.

Quick Access Functions: Swipe the dial interface to rapidly access functions such as heart rate monitoring, sleep tracking, weather, music, and positioning.

Women's Health Tracking: Features include reminders for menstruation and ovulation, as well as a safety period calculator.

Games: The watch includes an interactive game titled "Birds of Prey".

Location Services: When the app is connected via Bluetooth 5.0, the watch displays real-time location data, subject to phone positioning permissions.

Additional Settings

Constant Light Time: Set the duration for the backlight to remain on.

Screen Timeout: Adjust the duration for the screen display.

Gesture Activation: Raise your wrist to illuminate the screen; toggle this feature on or off as needed.

Brightness Control: Modify the screen brightness to your comfort level.

Do Not Disturb Mode: Enable to silence notifications either continuously or according to a specified schedule.

Drainage Function: Improve drainage by vigorously shaking the wristband.

Password Setting: Assign a personal password for access. If forgotten, the password can be reset using the default code '8888'.

Phone Connection: Scan the provided QR code with your smartphone to initiate the download of the EferFit APP.

Power Saving Mode: Activate to dim the screen and disable vibration, conserving battery life.

Language Options: Offers multi-language support. Select your preferred language as needed.

Time Adjustment: Synchronize the time with the app or personalize it manually.

Date Configuration: Set the date through the app synchronization or adjust it to your preference.

Factory Reset: In case of software issues, revert to the original factory settings for resolution.

Power Down: Shut down the watch by entering the power off mode.

Device Information: Access details about the watch model, software version, and MAC address in the 'About' section.

Warranty

Exclusion

- Porodo doesn't cover any damage caused by the normal use of the product over time during the warranty period.
- The Porodo warranty doesn't include coverage for improper use, deliberate damage, accidents, theft, carelessness, or any repairs done by unauthorized service centers.
- The power needs for each product are clearly stated on their packages. Please check these requirements against those of your country before buying. Porodo won't be responsible for any problems related to this.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: [porodo](https://www.instagram.com/porodo)